


INSTALLATION GUIDE



XRSUPER6 / XR20 / XR40 COMMAND PROCESSOR™ PANELS

MODEL XRSuper6/XR20/XR40 COMMAND PROCESSOR INSTALLATION GUIDE

FCC NOTICE

This equipment generates and uses radio frequency energy and, if not installed and used properly in strict accordance with the manufacturer's instructions, may cause interference with radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specification in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the installer is encouraged to try to correct the interference by one or more of the following measures:

Reorient the receiving antenna

Relocate the computer with respect to the receiver

Move the computer away from the receiver

Plug the compute into a different outlet so that computer and receiver are on different branch circuits

If necessary, the installer should consult the dealer or an experienced radio/television technician for additional suggestions. The installer may find the following booklet, prepared by the Federal Communications Commission, helpful:

“How to identify and Resolve Radio-TV Interference Problems.”

This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402

Stock No. 004-000-00345-4

© 2008 Digital Monitoring Products, Inc.

Information furnished by DMP is believed to be accurate and reliable.

This information is subject to change without notice.

Revisions to This Document

Panel Specifications

1.1	Power Supply	1
1.2	Communication.....	1
1.3	Panel Zones.....	1
1.4	Keypads	1
1.5	Outputs.....	1
1.6	Enclosure Specifications	1

Introduction

2.1	Description	2
2.2	System Configurations.....	2
2.3	Before You Begin	2
2.4	About this Guide	2
2.5	How to Use this Guide.....	2

System Components

3.1	Description	3
3.2	Wiring Diagram.....	3
3.3	Lightning Protection	3
3.4	Accessory Devices.....	3
3.4	Accessory Devices continued	4
3.5	XRSuper6/XR20/XR40 Wiring Diagram.....	4

Installation

4.1	Mounting the Enclosure.....	5
4.2	Mounting Keypads	6
4.3	Installation Specifications	6

Primary Power Supply

5.1	AC terminals 1 and 2.....	6
5.2	Transformer Types	6

Secondary Power Supply

6.1	Battery Terminals 3 and 4.....	7
6.2	Earth Ground.....	7
6.3	Replacement Period	7
6.4	Discharge/Recharge	7
6.5	Battery Supervision	7
6.6	XRSuper6/XR20/XR40 Power Requirements	7
6.7	XRSuper6/XR20/XR40 Standby Battery Calculations	8

Bell Output

7.1	Terminals 5 and 6	9
-----	-------------------------	---

Keypad Data Bus

8.1	Description	9
8.2	Terminal 7 - RED.....	9
8.3	Terminal 8 - YELLOW	9
8.4	Terminal 9 - GREEN.....	9
8.5	Terminal 10 - BLACK	9
8.6	Programming Connection	9
8.7	Keypad Addressing.....	9

Smoke and Glassbreak Detector Output

9.1	Terminal 11	9
-----	-------------------	---

Burglary Zones

10.1	Description	10
10.2	Operational Parameters.....	10
10.3	Zone Response Time.....	10
10.4	Keyswitch Arming Zone	10

Powered Zone for 2-Wire Smoke Detectors

11.1	Terminals 25 and 26.....	11
------	--------------------------	----

TABLE OF CONTENTS

Annunciator Outputs	
12.1	Description12
12.2	Harness Wiring12
12.3	Model 860 Relay Module.....12
Telephone RJ Connector	
13.1	Description13
13.2	FCC Registration13
13.3	Notification.....13
13.4	Ground Start13
Reset Jumpers J16	
14.1	Description14
15.1	Introduction14
15.2	Wiring.....14
15.3	Police Station Phone Numbers14
15.4	Bypass Reports.....14
15.5	System Maintenance14
15.6	Cross-Zoning14
15.7	Ground Start14
15.8	Listed Receivers.....14
ANSI/UL 1023 Specifications	
16.1	Bell Cutoff.....15
16.2	Entry Delay15
16.3	Exit Delay.....15
16.4	Zone Expansion on 4-Wire Bus.....15
16.5	Wireless External Contact15
16.6	Wireless Supervision Time15
16.7	Wireless Audible Annunciation15
ANSI/UL 1610 and ANSI/UL 1076 Specifications	
17.1	Opening/Closing Reports15
17.2	Automatic Bell Test15
17.3	Proprietary Dialer.....15
17.4	Standard Line Network Security15
17.5	Wireless Arming Mode.....15
17.6	Wireless Tamper15
17.7	Wireless External Contact15
17.8	Wireless Supervision Time16
17.7	Wireless Audible Annunciation16
ANSI/UL 636 Specifications	
18.1	UL 1610 Required16
18.2	1100D Wireless Receiver16
18.3	Wireless Supervision Time16
18.4	LED Display16
18.5	Jamming Detection16
18.6	Local Alarm16
18.7	Message to Transmit16
18.8	Wireless Audible Annunciation16
ANSI/UL 1635 Specifications	
19.1	Digital Dialer Telephone Number16
19.2	Entry Delay16
19.3	Exit Delay.....16
19.4	Test Frequency16
19.5	Automatic Bell Test16
19.6	DACT Central Station16
ANSI/UL 365 Specifications	
20.1	Entry Delay17
20.2	Bell17
20.3	Bell Cutoff17
20.4	Automatic Bell Test17

TABLE OF CONTENTS

20.5	Mercantile	17
20.6	Mercantile Safe and Vault	17
20.7	Line Security for Police Connect	17
20.8	Standard Line Network Security	17
20.9	Wireless Arming Mode.....	17
20.10	Wireless Tamper	17
20.11	Wireless External Contact	17
20.12	Wireless Supervision Time	17
20.13	Wireless Audible Annunciation	17
ANSI/UL 609 Specifications		
21.1	Entry Delay	18
21.2	Bell	18
21.3	Bell Cutoff	18
21.4	Automatic Bell Test	18
21.5	Mercantile Safe and Vault	18
21.6	Wireless Arming Mode.....	18
21.7	Wireless Tamper	18
21.8	Wireless External Contact	18
21.9	Wireless Supervision Time	18
21.10	Wireless Audible Annunciation	18
Universal Fire Alarm Specifications		
22.1	Introduction	19
22.2	Wiring	19
22.3	Police Station Phone Number	19
22.4	System Maintenance	19
22.5	Audible Alarm	19
22.6	Fire zone programming	19
22.7	Ground Start	19
22.8	Listed Receivers.....	19
ANSI/UL 985 NFPA 72 (Chapter 2) Specifications		
23.1	Bell Output Definition	19
23.2	Indicating Circuit Supervision	19
23.3	Wireless External Contact	19
23.4	Wireless Supervision Time	19
23.5	Wireless Fire Verification.....	19
California State Fire Marshal Specifications		
24.1	Bell Output Definition	19
False Alarm Reduction Programmable Options *		
25.1	Shipping Defaults and Recommended Programming for ANSI/SIA CP-01-2000 ..	20
25.2	Call Waiting (ANSI/SIA CP-01-2000)	21
25.3	Occupied Premise (ANSI/SIA CP-01-2000)	21
25.4	Entry Delay (ANSI/SIA CP-01-2000)	21
25.5	Local Bell (ANSI/SIA CP-01-2000)	21
25.6	Minimum Installation Requirements (ANSI/SIA CP-01-2000)	21
Troubleshooting		
26.1	Troubleshooting Section	22
26.2	Common LCD Keypad Displays.....	22
Wiring Diagrams		
27.1	Multiple Indicating Circuit Module Install.	23
27.2	Install for Derived Channel Burglary	24
OPERATING INSTRUCTIONS MODEL XRSuper6/XR20/XR40		
PANELS		
	Mounting Instructions	25
Listings and Approvals..... 25		

Revisions to This Document

This section explains the changes that were made to this document during this revision. This section lists the date the change was made, the section number and heading, and a quick summary of the change.

Ver.	Section Number and Heading	Summary of Changes
1.02	3.5 Wiring Diagram	Removed reference to Grades of Service
	17.4 Network Security	Replaced AA High Line with Standard Line
	19.6 DACT Central Station	Removed reference to Grades of Service
	20.1 Entry Delay	Removed reference to Grades of Service
	20.5 Mercantile	Removed reference to Grades of Service
	20.8 Standard Line Network Security	Replaced AA High Line with Standard Line
	20.2 Bell	Added to the specification
	21.1 Entry Delay	Added section
	21.2 Bell	Added section
	21.3 Bell Cutoff	Added section
1.01	21.4 Automatic Bell Test	Added section
	21.5 Mercantile Safe and Vault	Added section
	21.6 Wireless Arming Mode	Added section
	21.7 Wireless Tamper	Added section
	21.8 Wireless External Contact	Added section
	21.9 Wireless Supervision Time	Added section
	21.10 Wireless Audible Annunciation	Added section
	3.4 Accessory Devices	Reorganized into summary table
	6.7 Standby Battery Calculations	Added 7360 and 7363 Thinline Series Icon keypads
	16.7 Wireless Audible Annunciation	Added section
17.7 Wireless Audible Annunciation	Added section	
18.8 Wireless Audible Annunciation	Added section	
20.13 Wireless Audible Annunciation	Added section	

Panel Specifications

1.1 Power Supply

Transformer Input: Wire-in – 16.5 VAC 40 VA, Model 320
 Plug-in – 16.5 VAC 40 VA, Model 321
 Standby Battery: 12 VDC 7.0 Ah (40 VA transformer charges up to 2 batteries)
 Auxiliary Output: 12 VDC at 500mA
 Bell Output: 12 VDC at 1.5 Amps
 Smoke Detector Output: 12 VDC at 100mA
 All circuits inherent power limited

1.2 Communication

Built-in SDLC Digital Dialer communication to DMP Model SCS-1R Receivers
 Built-in 4-2 communication to non-DMP receivers
 Built-in M2E (Radionics Modem IIe) communication to non-DMP receivers
 Built-in CID (Contact ID) communication to non-DMP receivers
 Any panel can operate as a local system.

1.3 Panel Zones

Nine 1k Ohm EOL burglary zones: zones 1 to 9 on XR20 and XR40 panels, and zones 1 to 5 on the XRSuper6.
 One 3.3k Ohm EOL Class B powered fire zone with reset capability: zone 6 on the XRSuper6, and zone 10 on XR20 and XR40 panels.

1.4 Keypads

You can connect up to four supervised keypads to the XRSuper6/XR20 panels and eight supervised keypads on the XR40.

- 16 or 32-character alphanumeric keypads
- 10-zone LED keypads

In addition, the following zone expanders can be added to the XRSuper6/XR20/XR40 panels:

- One, four, eight and 16-zone expansion modules
- Single-zone PIR and glassbreak detectors
- One 738A Ademco Wireless interface for up to 32 points of zone expansion
- One FA426 Wireless receiver for up to 16 points of zone expansion (Two FA426 on the XR40)

When using the FA426 Wireless Receiver, you can add unsupervised devices to address five of the XRSuper6 and XR20.

1.5 Outputs

The XRSuper6/XR20/XR40 panels provide four open collector outputs rated for 50mA each. A Model 300 Output Harness is required. The open collector outputs provide the ground connection for a positive voltage source.

1.6 Enclosure Specifications

The XRSuper6/XR20/XR40 panel ships in an enclosure with EOL resistors, battery leads, user's guide, and programming sheet.

Enclosure Model	Size	Color(s)	Construction (Cold Rolled Steel)
340	12.5" W x 9.5" H x 2.75" D	Gray (G)	20-Guage
349	12.5" W x 11.25" H x 3.5" D	Gray (G)	20-Guage
350	17.5"W x 13.5"H x 3.5"D	Gray (G) or Red (R)	18-Guage
350A	17.5"W x 13.5"H x 3.6"D	Gray (G)	18-Guage with 16-Guage door
341	12.75"W x 6.55"H x 2.9"D	Gray (G)	20-Guage

Introduction

2.1 Description

The DMP XRSuper6/XR20/XR40 Command Processor™ panels are powerful 12 VDC burglary and fire communicator panels with battery backup. The XR20 and XR40 panels provide nine on-board burglary zones and one on-board 12 VDC Class B powered fire zone. The XRSuper6 provides five burglary zones and one fire zone. The fire zone has a reset capability to provide for 2-wire smoke detectors, relays, or other latching devices. The panels can communicate to one or two DMP SCS-1R Receivers using SDLC digital dialer, 4-2, or Contact ID (CID) reporting formats. In addition, the XRSuper6/XR20/XR40 can communicate using the Radionics Modem IIe format.

2.2 System Configurations

The panels can be programmed to operate as either an All/Perimeter system that provides one Perimeter area and one Interior area, or as a Home/Sleep/Away system that provides one Perimeter, one Interior, and one Bedroom area. The Bedroom area can include any protection devices the user wants disarmed during their sleeping hours and armed in the Away mode. In addition, the XR20/XR40 can operate as a four area system.

2.3 Before You Begin

Before installing the panel, we recommend you read through the entire contents of this guide. Familiarize yourself with the features of the panel and the key points to remember during the installation. Be sure to read and understand all of the caution statements printed in bold italics. In addition to this installation guide, you should also read through and familiarize yourself with these other product documents:

- XRSuper6/XR20/XR40 Programming Guide (LT-0305)
- XR20 Security Command User's Guide (LT-0303)
- XRSuper6 Programming Sheet (LT-0621)
- XR40 Programming Sheet (LT-0493)
- XRSuper6 Security Command User's Guide (LT-0622)
- XR40 Security Command User's Guide (LT-0494)
- XR20 Program Information Sheet (LT-0302)

2.4 About this Guide

The information contained in this guide is organized into five sections:

- The **Table of Contents** at the front of this guide lists all of the headings and the page number where the information can be found.
- The **Introduction** section gives you an overview of the various components that go into a panel system and diagrams some typical system configurations.
- The **Installation** section begins with mounting instructions for the enclosure and takes you through the proper way to power up the panel prior to programming.
- The **Compliance** section lists various standards to which the panels comply.
- The **Wiring Diagram** section provides common system drawings for the panels.

Caution notes

Throughout this guide you will see caution notes containing information you need to know when installing the panel. These cautions are indicated with a yield sign. Whenever you see a caution note, make sure you completely read and understand its information. Failing to follow the caution note can cause damage to the equipment or improper operation of one or more components in the system. See the example shown below.



Always ground the panel before applying power to any devices: The panel must be properly grounded before connecting any devices or applying power to the panel. Proper grounding protects against Electrostatic Discharge (ESD) that can damage system components.

2.5 How to Use this Guide

To locate information about the installation of the panel, first go to the Table of Contents at the front of this guide. Find the subject heading that closely describes the information you need and turn to the section number shown to the right of the heading.

The text that follows the heading has been written to provide as much information about the subject as possible. If you cannot find the information you need under that heading, try scanning through a few of the headings before and after and reading the text under those that sound similar.

System Components

3.1 Description

The DMP system is made up of an alarm panel with built in communicator, an enclosure, a 16.5 VAC transformer, and a 12 VDC 7.0 Ah battery. You can add Security Command keypads to the system and can also connect auxiliary devices to the panel's open collector outputs to expand the basic system. Combined current requirements of additional modules may require an auxiliary power supply. Refer to the Standby Battery Power Calculation section in this guide when calculating power requirements. In addition, up to 32 points of zone expansion can be added to the XR40, and 16 points to the XR20 and XRSuper6.

3.2 Wiring Diagram

The system wiring diagram in Figure 1, on the following page, shows some of the accessory devices you can connect for use in various applications. A complete description of each module follows.

3.3 Lightning Protection

Metal Oxide Varistors and Transient Voltage Suppressors help protect against voltage surges on input and output circuits. A transorb is provided for the Smoke Detector Output Circuit (Terminal 11). This transient protection provides additional resistance to electrical surges such as lightning. Additional surge protection is available by installing the DMP 370 or 370RJ Lightning Suppressors.

3.4 Accessory Devices

Interface Adaptor and Interface Cards	
733, 734 Wiegand Interface Cards	Provides system codeless entry, and arming and disarming using access control readers.
Zone and Output Expansion Modules	
710 Bus Splitter/Repeater	Allows you to increase keypad wiring distance to 2500 feet.
711 Single Point Zone Expanders	Provides one Class B zone for connecting burglary devices.
714, 714-8, 714-16 Zone Expanders	Provides Class B zones for connecting burglary and non-powered fire devices.
712-8 Zone Expander	Provides Class B zones for connecting burglary devices.
715, 715-8, 715-16 Zone Expanders	Provides 12 VDC Class B powered zones for connecting smoke detectors, glassbreak detectors, and other 2- or 4-wire devices.
DMP Two-Way Wireless Devices	
1100D/*1100DH/*1100DI Wireless Receivers	Supports transmitters in residential or commercial wireless operation.
1101 Universal Transmitter	Provides both internal and external contacts that may be used at the same time to yield two individual reporting zones from one wireless transmitter.
1102 Universal Transmitter	Provides an external contact.
* 1114 Four-Zone Expander	Provides four wireless zones
* 1116 Relay Output	Provides one Form C relay
* 1117 LED Annunciator	Provides a visual system status indicator
* 1121 PIR Motion Detector	Provides motion detection with pet immunity.
1125 PIR Motion Detector	Provides multiple lens configurations, dual coverage area selection, and sensitivity adjustments.
* 1129 Glassbreak Detector	Detects the shattering of framed glass mounted in an outside wall and provides full-pattern coverage and false-alarm immunity.
* 1139 Bill Trap	Provides a silent alarm option for retail and banking cash drawers.
1142BC Two-button Panic Belt Clip Transmitter	Provides portable two-button panic operation.
1142 Two-button Panic Transmitter	Provides permanently mounted under-the-counter two-button panic operation.
* 1145 (Four-Button) * 1146 (Two-Button) * 1147 (One-Button)	Key Fob transmitters designed to clip onto a key ring or lanyard.
*These devices have not been investigated by a Nationally Recognized Testing Laboratory (NRTL).	

3.4 Accessory Devices continued

1161 Residential Smoke Detector	Residential smoke detector with sounder.
1162 Residential Smoke Detector	Residential smoke/heat detector with sounder and fixed rate-of-rise heat detector
Accessory Modules and Keypads	
iCOMsl Network Alarm Router	Allows network connection for alarm communication
* ePAD™ Virtual Keypads	Allows users to control the security system from any computer in the world using the Internet.
LCD keypads	Allows you to control the panel from various remote locations. Connect up to four keypads on XRSuper6 and XR20, and up to eight keypads on the XR40. Model 690/690F, 790/790F, 693/793 Security Command™ keypads, 7060/7160, 7063/7163, 7070/7170, 7073/7173 Thinline™ keypads, 7060A, 7063A, 7070A, 7073A Aqualite™ keypads, 7360, 7363 Thinline Icon Series keypads, or 7760 Clear Touch™ keypad to the keypad bus using terminals 7, 8, 9, and 10.
* These devices have not been investigated by a Nationally Recognized Testing Laboratory (NRTL).	

3.5 XRSuper6/XR20/XR40 Wiring Diagram




Figure 1: System Wiring Diagram

Installation

4.1 Mounting the Enclosure

The metal enclosure must be mounted in a secure, dry place to protect the panel from damage due to tampering or the elements. It is not necessary to remove the PCB when installing the enclosure. The PCB may be installed in the standard 340 enclosure the optional 349 Medium enclosure or 341 Kiosk enclosure. The XRSuper6, XR20, or XR40 panels may optionally be installed in the 350A Grade A enclosures.

Note: When using the Model 341 enclosure for UL Listed applications, use the Model 350, 349, 341, or 352S enclosure for standby batteries.




Figure 2: Standard 340 Enclosure (left) or Optional 349 Enclosure (right)




Figure 3: Optional 341 Enclosure

INSTALLATION

4.2 Mounting Keypads

DMP keypads have removable covers that allow the base to be mounted on a wall or other flat surface using the screw holes provided on each corner.

For mounting keypads on solid walls, or for applications where conduit is required, use a DMP 695, 696, 775, or 776 keypad conduit backbox.

4.3 Installation Specifications

Several factors determine the performance characteristics of the keypad bus: the length of wire used, the number of devices connected, and the voltage at each device. When planning a keypad bus installation, keep in mind the following four specifications:

1. DMP recommends using 18 or 22-gauge **unshielded** wire for all keypad circuits. **Do not** use twisted pair or shielded wire for keypad bus data circuits. All 22-gauge wire must be connected to a power-limited circuit and jacket wrapped.
2. On keypad bus circuits, to maintain auxiliary power integrity when using 22-gauge wire do not exceed 500 feet. When using 18-gauge wire do not exceed 1,000 feet. To increase the wire length or to add devices, install an additional power supply that is UL listed for Fire Protective Signaling, power limited, and regulated (12 VDC nominal) with battery backup.
Note: Each panel allows a specific number of supervised keypads. Add additional keypads in the unsupervised mode. Refer to the panel installation guide for the specific number of supervised keypads allowed.
3. Maximum distance for any one bus circuit (length of wire) is 2,500 feet regardless of the wire gauge. This distance can be in the form of one long wire run or multiple branches with all wiring totaling no more than 2,500 feet. As wire distance from the panel increases, DC voltage on the wire decreases.
4. Maximum voltage drop between the panel (or auxiliary power supply) and any device is 2.0 VDC. If the voltage at any device is less than the required level, add an auxiliary power supply at the end of the circuit. When voltage is too low, the devices cannot operate properly.

For additional information refer to the 710/710F Installation Sheet (LT-0310) and or the LX-Bus/Keypad Bus Wiring Application Note (LT-2031).




Figure 4: Wiring Multiple Batteries

Primary Power Supply

5.1 AC terminals 1 and 2

Connect the transformer wires to terminals 1 and 2 on the panel. Use no more than 70 ft. of 16 gauge, or 40 ft. of 18 gauge, wire between the transformer and the panel.



Always ground the panel before applying power to any devices: The panel must be properly grounded before connecting any devices or applying power to the panel. Proper grounding protects against Electrostatic Discharge (ESD) that can damage system components. See Earth ground, in the Secondary Power Supply section.

5.2 Transformer Types

The transformer for the panel is 16.5 VAC 40 VA, which provides up to 1.5 Amps of bell output current, 500mA of auxiliary current, and 100mA of smoke detector output. You can use either the Model 320 wire-in or 321 plug-in transformer with the panel. The total current available is limited by the total battery standby requirements of the installation.



The transformer must be connected to a 120 VAC 60 Hz commercial power outlet that is not controlled by a wall switch. **Never share the transformer output with any other equipment.**

Secondary Power Supply

6.1 Battery Terminals 3 and 4

Connect the black battery lead to the negative battery terminal. The negative terminal connects to the enclosure ground internally through the XRSuper6, XR20, or XR40 circuit board. Connect the red battery lead to the positive battery terminal. Observe polarity when connecting the battery.

Add a second battery in parallel using the DMP Model 318 Dual Battery Harness. **DMP requires each battery be separated by a PTC in the battery harness wiring to protect each battery from a reversal or short within the circuit. See Figure 4.**



Use sealed lead-acid batteries only: Use the DMP Model 367, 12 VDC 7.0 Ah sealed lead-acid rechargeable battery. Batteries supplied by DMP or manufactured by Eagle Picher or Yuasa have been tested to ensure proper charging with DMP products.

GEL CELL BATTERIES CANNOT BE USED WITH THE XRSuper6/XR20/XR40 PANEL.

6.2 Earth Ground

Terminal 4 of the panel must be connected to earth ground using 14 gauge or larger wire to provide proper transient suppression. DMP recommends connecting to a metal cold water pipe or ground rod only. Do not connect to electrical conduit or a telephone company ground.

6.3 Replacement Period

DMP recommends replacing the battery every 3 to 5 years under normal use.

6.4 Discharge/Recharge

The panel battery charging circuit float charges at 13.9 VDC at a maximum current of 1.2 Amps using a 40 VA transformer. The total current available is reduced by the combined auxiliary current draw from terminals 7, 11, and 25. The various battery voltage levels are listed below:

Battery Trouble:	Below	11.9 VDC
Battery Restored:	Above	12.6 VDC

6.5 Battery Supervision

The panel tests the battery once every hour when AC power is present. This test occurs 15 minutes past each hour and lasts for five seconds. A load is placed on the battery and if its voltage falls below 11.9 VDC a low battery is detected. If AC power has failed, a low battery is detected any time the battery voltage falls below 11.9 VDC.

If a low battery is detected with AC power present, the test is repeated every two minutes until the battery charges above 12.6 VDC; the battery restored voltage. If a faulty battery is replaced with a fully charged battery, the restored battery will not be detected until the next two-minute test is done.

6.6 XRSuper6/XR20/XR40 Power Requirements

During AC power failure, the panel and all auxiliary devices connected draw their power from the battery. All devices must be taken into consideration when calculating the battery standby capacity. On the following page is a list of the power requirements of the panel. Add the additional current draw of DMP keypads, smoke detector output, and any other auxiliary devices used in the system for the total current required. The total is then multiplied by the total number of standby hours required to arrive at the total Ampere-hours required.

Bell Output

7.1 Terminals 5 and 6

Nominal 12 VDC is supplied by terminal 5 on the panel to power alarm bells or horns. The output is rated for a maximum of 1.5 Amps with a 40 VA transformer. This output can be steady, pulsed, or Temporal Code 3 depending upon the Bell Action specified in Output Options programming. Terminal 6 is the ground reference for the bell circuit.

Keypad Data Bus

8.1 Description

Terminals 7, 8, 9, and 10 of the panel are designated as the keypad data bus. In addition to keypads, the XRSuper6/XR20/XR40 allows the connection of any combination of zone expansion modules, 5845LX Glassbreak Detectors, and 6155LX PIRs, to the keypad bus up to the maximum of four devices. The XRSuper6 allows the connection of four zones on address one.

8.2 Terminal 7 - RED

Nominal 12 VDC is supplied at terminal 7 to power Security Command keypads and zone expanders. This is also where power for any auxiliary device is supplied. The ground reference for terminal 7 is terminal 10. The maximum output is rated at 500mA. All auxiliary devices totaled together must not exceed the panel's maximum current rating of 500mA.

8.3 Terminal 8 - YELLOW

Data receive from keypads and zone expanders.

8.4 Terminal 9 - GREEN

Data transmit to keypads and zone expanders.

8.5 Terminal 10 - BLACK

Terminal 10 is the ground reference for Security Command keypads, zone expanders, and any auxiliary devices being powered by terminals 7 and 11.

8.6 Programming Connection

A locking 4-pin header (J8) is provided to connect a keypad when using a DMP Model 330 Programming Cable. This provides a quick and easy connection for programming the panel.

8.7 Keypad Addressing

Address	XRSuper6 Zone Number	XR20 Zone Number	XR40 Zone Number
Panel Zones	1-6	1-10	1-10
1	7-10	11-14	11-14
2	21-24	21-24	21-24
3	31-34	31-34	31-34
4	41-44	41-44	41-44
5	*	*	51-54
6	N/A	N/A	61-64
7	N/A	N/A	71-74
8	N/A	N/A	81-84

* **Note:** Address 5 can be used with unsupervised keypads. This allows all 16 zones to be used by Zone Expansion Modules, such as a 714-16.

Smoke and Glassbreak Detector Output

9.1 Terminal 11

Nominal 12 VDC at 100mA maximum (shared by terminal 25) is supplied at terminal 11 to power 4-wire smoke detectors or other auxiliary powered devices. This output can be turned off by the user for 5 seconds using the Sensor Reset option in the User Menu. Terminal 10 is the ground reference for terminal 11.

Burglary Zones

10.1 Description

On XR20/XR40 panels, terminals 12 to 24 are the nine burglary zones. For programming purposes, the zone numbers are 1 to 9. The zone configurations on terminals 12 to 24 are described below. The XRSuper6 terminals 12 to 18 are the five burglary zones with terminal 16 providing the ground for zone 5 (terminal 18).

Terminal	Function	Terminal	Function
12	Zone 1 voltage sensing	19	Ground for zones 5 & 6
13	Ground for zones 1 & 2	20	Zone 6 voltage sensing
14	Zone 2 voltage sensing	21	Zone 7 voltage sensing
15	Zone 3 voltage sensing	22	Ground for zones 7, 8, & 9
16	Ground for zones 3 & 4 (& 5 on XRSuper6)	23	Zone 8 voltage sensing
17	Zone 4 voltage sensing	24	Zone 9 voltage sensing
18	Zone 5 voltage sensing		

The voltage sensing terminal measures the voltage across the 1k Ohm End-of-Line resistor and the zone's ground terminal. Dry contact sensing devices can be used in series (normally-closed) or in parallel (normally-open) with any of the burglary protection zones.

10.2 Operational Parameters

Each burglary protection zone detects three conditions: open, normal, and short.

The parameters for each are listed below:

Condition	Resistance on zone	Voltage on right terminal
Open	over 1300 ohms	over 2.0 VDC
Normal	600 to 1300 ohms	1.2 to 2.0 VDC
Short	under 600 ohms	under 1.2 VDC




Figure 5: Protection Zone Contact Wiring

10.3 Zone Response Time

A condition must be present on a zone for 500 milliseconds before it is detected by the panel. Ensure detection devices used on the protection zones are rated for use with this delay.

10.4 Keyswitch Arming Zone

You can use a momentary keyswitch on a zone programmed as an Arming type for use in arming and disarming the system without a code.

Powered Zone for 2-Wire Smoke Detectors

11.1 Terminals 25 and 26

A resettable 2-wire Class B powered zone is provided on terminals 25 (positive) and 26 (negative) of the panel. For programming purposes, the zone number is 10 on the XR20/XR40 and zone 6 on the XRSuper6. The zone uses a Model 309, 3.3k Ohm EOL resistor (provided with the panel) and has an operating range of 8.8 to 14.2 VDC.

The UL compatibility identifier is: A.

Caution: Sensor reset on zone 10 (zone 6 on the XRSuper6) will drop power to devices on this zone, causing the panel to sense an open condition on all zone types other than Fire, Fire Verify, and Supervisory.

Whenever non-Fire and non-Supervisory zone types are used on zone 10, make the appropriate adjustments to the zone's Armed Action to prevent false alarms from occurring.

Manufacturer	Model	Detector ID	Base	Base ID	# of Detectors	Zone Expansion Modules
Detection Systems	DS250, DS250TH	B	MB2W, MB2WL	A	10	715, 715-8, 715-16, 725
Detection Systems	DS250HD	B	MB2W, MB2WL	A	10	715, 715-8, 715-16
Detection Systems	DS282, DS282TH	B			10	715, 715-8, 715-16, 725
DMP/Hochiki	SLK-835	HD-5	HSB-200, HSB-200N	HB-55	7	715, 715-8, 715-16
DMP/Hochiki	SLR-835	HD-3	NS6-100	HB-55	7	715, 715-8, 715-16, 725
DMP/Hochiki	SLR-835B	HD-6			7	715, 715-8, 715-16, 725
Sentrol/ESL	429AT, 521B, 521BXT	S09A			12	715, 715-8, 715-16
System Sensor	1100, 1400	STD			10	715
System Sensor	1151, 2151	STD	B110PL, B401		10/10	715, 725
System Sensor	1451, 2451TH	STD	B401, B401B		10	715
System Sensor	1451DH	STD	DH400		10	715
System Sensor	2100, 2100T	STD			10	715
System Sensor	2100S, 2100TS	A			12	725
System Sensor	2400, 2400AT, 2400AIT, 2400TH	STD			10	715
System Sensor	2451	STD	B401, B401B, DH400		10	715
System Sensor	2W-B, 2WT-B	A			10	715, 715-8, 715-16

Annunciator Outputs

12.1 Description

The four annunciator outputs can be programmed to indicate the activity of the panel's zones or conditions occurring on the system. Annunciator outputs do not provide a voltage but instead switch-to-ground voltage from another source. The outputs can respond to any of the conditions listed below:

- 1) Activation by zone condition: Steady, Pulse, Momentary, or Follower
- 2) Manually from the keypad
- 3) Communication failure
- 4) Armed area annunciation
- 5) Fire Alarm or Fire Trouble
- 6) Ambush alarm
- 7) Exit and Entry timers
- 8) System Ready
- 9) Ground start activation
- 10) Cellular Backup
- 11) Late to Close

12.2 Harness Wiring

The open collector outputs are accessible by installing the DMP 300 Harness on the 4-pin header labeled J11. The output locations are shown below. For UL applications, devices connected to the outputs must be located within the same room as the panel.

Output	Color	Wire	Output	Color	Wire
1	Red	1	3	Green	3
2	Yellow	2	4	Black	4

12.3 Model 860 Relay Module

Connect a Model 860 Relay Module to the panel to provide relays for the annunciator outputs that can be used for electrical isolation between the alarm panel and other systems or for switching voltage to control various functions. The module includes one relay and provides three additional sockets for expansion of up to four relays. Power is supplied to the relay coils from the panel keypad bus. The 860 mounts inside the panel enclosure using the 3-hole mounting configuration. Plastic standoffs are provided with the module for ease of installation. A 4-wire harness is also provided that connects the Model 860 to the DMP panel.

Relay Contact Rating: 1 Amp at 30 VDC

Telephone RJ Connector

13.1 Description

Connect the panel to the public telephone network by installing a DMP 356 RJ Cable between the panel's J4 connector and the RJ31X or RJ38X phone jack.

A two pin header labeled RJ SUP (J7) is provided to allow monitoring of the telephone cable connected between the panel and a RJ38X jack (pins 2 and 7 jumpered). Attach a DMP Model 306 Harness between J7 and any available zone. The J7 pins are connected via the telephone cable to the RJ38X jack pins 2 and 7. The RJ38X jack provides a jumper between pins 2 and 7 which completes the circuit. Program the zone as a Supervisory type (SV). When the telephone cable is removed, the keypad displays zone trouble and produces a steady tone.




Figure 7: Phone Jack Wiring

13.2 FCC Registration

The panel complies with FCC part 68 and is registered with the FCC.

Registration number: CCKUSA - 18660 - AL - R

Ringer Equivalence: 1.1B

13.3 Notification

Registered terminal equipment must not be repaired by the user. In case of trouble, the device must be immediately unplugged from the telephone jack. The factory warranty provides for repairs. Registered terminal equipment may not be used on party lines or in connection with coin telephones. Notification must be given to the telephone company with the following information:

- a. The particular line(s) the service is connected to
- b. The FCC registration number
- c. The ringer equivalence
- d. The make, model, and serial number of the device

13.4 Ground Start

To configure the panel for ground start operation, you must install the appropriate ground start module and program one of the panel's available annunciator outputs for Ground Start operation. Refer to the panel Programming Guide for complete programming information. This option must not be selected on a UL listed system.

Reset Jumpers J16

14.1 Description

A pair of jumper wires are located at the top right of the panel circuit board labeled RESET. Momentarily shorting these jumper wires allows you to reset the microprocessor. Resetting the panel allows you to enter the panel’s internal programmer.

To reset the panel when first installing the system, place the blade of a slotted screwdriver across the two reset jumper wires after applying power to the panel.

To reset the panel while the system is operational (for example, prior to reprogramming), you can short the jumper wires without powering down the system.

After resetting the panel for programming, you must begin within 30 minutes. If you wait longer than 30 minutes, you will have to reset the panel again.




Figure 8: XRSuper6, XR20, XR40 Panel Showing the Reset Jumper Wires

Universal Burglary Specifications

15.1 Introduction

The programming and installation specifications contained in this section must be completed when installing the XRSuper6/XR20/XR40 in accordance with any of the UL burglary standards. Additional specifications may be required by a particular standard.

15.2 Wiring

All wiring must be in accordance with NEC, ANSI/NFPA 70, UL 681, and UL 611 for all burglary installations.

15.3 Police Station Phone Numbers

The digital dialer telephone number programmed for communication must not be a police station phone number, unless that phone number is specifically provided for that purpose.

15.4 Bypass Reports

The bypass reports must be programmed as YES for all UL burglary applications. See LT-0305.

15.5 System Maintenance

Proper installation and regular maintenance by the installing alarm company and frequent testing by the end user is essential to ensure continuous satisfactory operation of any alarm system. Offering a maintenance program and acquainting the user with the correct procedure for use and testing of the system is also the responsibility of the installing alarm company.

15.6 Cross-Zoning

Zones used for cross zoning must detect the same event and shall not conflict with UL 681 or 1641.

15.7 Ground Start

Ground Start phone lines must not be used for UL listed systems.

15.8 Listed Receivers

Operation has been verified with the DMP SCS-1R Security Receivers, Sur-Gard MLR2-E, SG-HLR2-DG, FBII CP220PB, Osborne-Hoffman Quick-Alert, and Radionics D6500 receivers.

ANSI/UL 1023 Specifications

Household Burglar-Alarm System Units

16.1 Bell Cutoff

The bell cutoff time cannot be less than five minutes. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

16.2 Entry Delay

The maximum entry delay used must not be more than 45 seconds. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

16.3 Exit Delay

The maximum exit delay used must not be more than 60 seconds. See the Programming Guide (LT-0305).

16.4 Zone Expansion on 4-Wire Bus

When expansion zones are used, the keypad and zone expander 4-wire bus must be limited to three feet in length unless an external communication fail indicator is added. A 12 VDC relay may be wired as a communication fail indicator. To install, connect the negative side of the indicator to one of the panel's annunciator outputs and the positive side to the smoke power (terminal 11 of the panel). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

In addition to the wiring described above, a 24-hour zone must be programmed to activate the appropriate annunciator output.

16.5 Wireless External Contact

When used, the External Contact of 1101, 1102, or 1103 must be programmed Normally Closed. See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

16.6 Wireless Supervision Time

The Zone Information Supervision Time cannot be set to 0 (zero). See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

16.7 Wireless Audible Annunciation

The Wireless Audible option must be selected as DAY for residential applications.

ANSI/UL 1610 and ANSI/UL 1076 Specifications

Central-Station and Proprietary Burglar-Alarm Units

17.1 Opening/Closing Reports

The Opening/Closing Reports option must be programmed as YES. See the Programming Guide (LT-0305).

17.2 Automatic Bell Test

This option must be programmed as YES. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

17.3 Proprietary Dialer

The Model XRSuper6/XR20/XR40 provide proprietary service when configured as a digital dialer.

17.4 Standard Line Network Security

Standard Line Security is provided when configured as a NET system using an XRSuper6, XR20, or XR40 panel with an iCOMSL™ Network Alarm Router. The NET Check-in time must be set from 01 to 06 minutes. When a dialer is required for 06 minute check-in time, an attack resistant enclosure (DMP Model 350A) is required. When the check-in time is set to a number less than 200 seconds (1, 2, or 3 minutes), an attack resistant enclosure is not required. See the Communication section of the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

17.5 Wireless Arming Mode

The System Options Mode for arming must be programmed as Area or All/Perimeter (A/P). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

17.6 Wireless Tamper

The Zone Information Disarmed Open Message to Transmit must be programmed Trouble (T). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

17.7 Wireless External Contact

When used, the External Contact of 1101, 1102, or 1103 must be programmed Normally Closed. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

17.8 Wireless Supervision Time

The Zone Information Supervision Time cannot be set to 0 (zero). See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

17.7 Wireless Audible Annunciation

The Wireless Audible option must be selected as ANY for commercial applications.

ANSI/UL 636 Specifications

Holdup Alarm Units

18.1 UL 1610 Required

The programming and installation specifications contained in this section must be completed in addition to UL 1610 Specifications when installing a Model 1142 with a Model XRSuper6/XR20/XR40 panel.

18.2 1100D Wireless Receiver

The Model 1100D Wireless Receiver in conjunction with the Model 1142 Holdup Alarm Transmitter must be installed in the system.

18.3 Wireless Supervision Time

The Zone Information Supervision Time must be a maximum of 60 minutes. See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

18.4 LED Display

The LED Operation option display must be set to NO when using a Model 1142 Holdup Alarm Transmitter. See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

18.5 Jamming Detection

The Detect Wireless Jamming option must be set to YES. See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

18.6 Local Alarm

The Bell Action for a PN (Panic) type zone must be programmed as N (None). See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

18.7 Message to Transmit

The Armed Open and Armed Short messages for a PN (Panic) type zone must be programmed to A (Alarm). See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

18.8 Wireless Audible Annunciation

The Wireless Audible option must be selected as ANY for commercial applications.

ANSI/UL 1635 Specifications

Digital Burglar Alarm Communicator System Units

19.1 Digital Dialer Telephone Number

Both programmed telephone numbers must begin with a D or P. See the Programming Guide (LT-0305).

19.2 Entry Delay

The maximum entry delay used must not be more than 60 seconds. See the Programming Guide (LT-0305).

19.3 Exit Delay

The maximum exit delay used must not be more than 60 seconds. See the Programming Guide (LT-0305).

19.4 Test Frequency

The Test Frequency option must be programmed to send a report once every 24 hours. See LT-0305.

19.5 Automatic Bell Test

This option must be programmed as YES. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

19.6 DACT Central Station

DACT Central Station service can be provided under UL 1635 by adding a local audible signal appliance and placing the XRSuper6/XR20/XR40 panel and all standby batteries into the Model 350A Attack Resistant Housing.

ANSI/UL 365 Specifications

Police Station Connected Systems

20.1 Entry Delay

The maximum entry delay must not exceed 60 seconds with the Model 350A housing. See LT-0305.

20.2 Bell

A local audible signal appliance must be used.

The alarm housing for a mercantile alarm system without a remote alarm transmission connection shall be mounted on the outside of the building, visible from a public street or highway. It shall be accessible for examination and repair. It shall also be located not more than four stories above the street level unless:

a) A second alarm sounding device and housing, intended for outside service, is mounted adjacent to the premises or area of the building in which the alarm system is installed or

b) A second alarm sounding device, intended for inside service, is mounted within the premises.

In either case, the outside alarm sounding device and housing may be mounted as high as the seventh floor.

20.3 Bell Cutoff

The bell cutoff time cannot be less than 15 minutes. See the Programming Guide (LT-0305).

20.4 Automatic Bell Test

The Automatic Bell Test option must be programmed as YES. See the Programming Guide (LT-0305).

20.5 Mercantile

For Mercantile and Police Station Connect operation the XRSuper6/XR20/XR40 panel and all standby batteries must be mounted in an attack resistant housing (DMP Model 350A).

20.6 Mercantile Safe and Vault

When the DMP Model 350A housing is used, the panel provides operation as a mercantile safe and vault alarm. Bell Supervision and wiring must be in accordance with UL 681. If the panel is mounted outside the safe or vault, tamper protection and the Sentrol Model 5402 or Potter EVD listed vibration detectors should be used. The XRSuper6/XR20/XR40 does not provide operation as a Bank Safe and vault alarm.

20.7 Line Security for Police Connect

Basic line security is provided when the Model XRSuper6/XR20/XR40 is configured as a dialer system.

20.8 Standard Line Network Security

Standard Line Security is provided when configured as a NET system using an XRSuper6, XR20, or XR40 panel with an iCOMSL™ Network Alarm Router. The NET Check-in time must be set from 01 to 06 minutes. When a dialer is required for 06 minute check-in time, an attack resistant enclosure (DMP Model 350A) is required. When the check-in time is set to a number less than 200 seconds (1, 2, or 3 minutes), an attack resistant enclosure is not required. See the Communication section of the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

20.9 Wireless Arming Mode

The System Options Mode for arming must be programmed as Area or All/Perimeter (A/P). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

20.10 Wireless Tamper

The Zone Information Disarmed Open Message to Transmit must be programmed Trouble (T). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

20.11 Wireless External Contact

When used, the External Contact of 1101, 1102, or 1103 must be programmed Normally Closed. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

20.12 Wireless Supervision Time

The Zone Information Supervision Time cannot be set to 0 (zero). See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

20.13 Wireless Audible Annunciation

The Wireless Audible option must be selected as ANY for commercial applications.

ANSI/UL 609 Specifications

Local Burglar Alarm Units and Systems

21.1 Entry Delay

The maximum entry delay must not exceed 60 seconds with the Model 350A housing. See LT-0305.

21.2 Bell

A local audible signal appliance must be used.

In a mercantile burglar alarm system, a mercantile alarm sounding device located within a building but outside the protected area, is acceptable, provided it is rated for outside service and alarm conditions are transmitted to:

- a) The dispatch location of the law enforcement agency having jurisdiction over the protected property or
- b) A central station or residential monitoring station complying with the Standard for Central Station Alarm Services, UL 827.

In a mercantile burglar alarm system, an alarm sounding device located within the area of greatest protection, or outside the area of greatest protection but within an area protected by an alarm system and that shares a common control unit with the system installed in the area of greatest protection, is acceptable provided it is rated for inside service and alarm conditions are transmitted to:

- a) The dispatch location of the law enforcement agency having jurisdiction over the protected property or
- b) A central station or residential monitoring station complying with the Standard for Central Station Alarm Services, UL 827.

An inside sounding device shall be mounted at least 10 feet (3.05 m) above the floor or at the surface of the ceiling. When there is fixed construction within the area that could provide access for an intruder, the alarm sounding device shall also be mounted at least 4 feet (1.2 m), as measured horizontally, away from the edges of the fixed construction or at least 10 feet (3.05 m) above it so as to minimize access by an intruder.

21.3 Bell Cutoff

The bell cutoff time cannot be less than 15 minutes. See the Programming Guide (LT-0305).

21.4 Automatic Bell Test

The Automatic Bell Test option must be programmed as YES. See the Programming Guide (LT-0305).

21.5 Mercantile Safe and Vault

When the DMP Model 350A housing is used, the panel provides operation as a mercantile safe and vault alarm. Bell Supervision and wiring must be in accordance with UL 681. If the panel is mounted outside the safe or vault, tamper protection and the Sentrol Model 5402 or Potter EVD listed vibration detectors should be used. The XRSuper6/XR20/XR40 does not provide operation as a Bank Safe and vault alarm.

21.6 Wireless Arming Mode

The System Options Mode for arming must be programmed as Area or All/Perimeter (A/P). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

21.7 Wireless Tamper

The Zone Information Disarmed Open Message to Transmit must be programmed Trouble (T). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

21.8 Wireless External Contact

When used, the External Contact of 1101, 1102, or 1103 must be programmed Normally Closed. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

21.9 Wireless Supervision Time

The Zone Information Supervision Time cannot be set to 0 (zero). See the XRSuper6, XR20, XR40 Programming Guide (LT-0305).

21.10 Wireless Audible Annunciation

The Wireless Audible option must be selected as ANY for commercial applications.

Universal Fire Alarm Specifications

22.1 Introduction

The programming and installation specifications contained in this section must be completed when installing the Model XRSuper6/XR20/XR40 in accordance with any of the UL or NFPA fire standards. Additional specifications may be required by a particular standard.

22.2 Wiring

All wiring must be in accordance with NEC, ANSI/NFPA 70.

22.3 Police Station Phone Number

The digital dialer telephone number programmed for communication must not be a police station phone number, unless that phone number is specifically provided for that purpose.

22.4 System Maintenance

Proper installation and regular maintenance by the installing alarm company and frequent testing by the end user is essential to ensure continuous satisfactory operation of any alarm system. Offering a maintenance program and acquainting the user with the correct procedure for use and testing of the system is also the responsibility of the installing alarm company.

22.5 Audible Alarm

Fire Type zones must be programmed to activate an audible alarm. The Bell Action for Fire Type zones must not be programmed as N (None). See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

22.6 Fire zone programming

Fire zones must be programmed to activate a trouble on open conditions and an alarm on short conditions. The swinger bypass function must not be used on any fire zones. See the Programming Guide (LT-0305).

22.7 Ground Start

Ground Start phone lines must not be used for UL listed systems.

22.8 Listed Receivers

Operation has been verified with the DMP SCS-1R Security Receiver, Sur-Gard MLR2-E, SG-HLR2-DG, FBII CP220PB, Osborne-Hoffman Quick-Alert, and Radionics D6500 receivers.

ANSI/UL 985 NFPA 72 (Chapter 2) Specifications

Household Fire Warning System Units

23.1 Bell Output Definition

The bell output of the Model XRSuper6/XR20/XR40 must be programmed to operate steady on burglary alarms and pulsed on fire alarms. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

23.2 Indicating Circuit Supervision

The DMP Models 865 and 866 Notification Circuit Module must be used on the bell circuit for detection of shorts and grounds.

23.3 Wireless External Contact

When used, the External Contact of 1101, 1102, or 1103 must be programmed Normally Closed. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

23.4 Wireless Supervision Time

The Zone Information Supervision Time must be 3 minutes. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

23.5 Wireless Fire Verification

When used, the Model 1161 and 1162 wireless smoke detectors must not be programmed as Fire Verification (FV) zone type. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

California State Fire Marshal Specifications

24.1 Bell Output Definition

The bell output of the Model XRSuper6/XR20/XR40 must be programmed to operate steady on burglary alarms and temporal on fire alarms. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

False Alarm Reduction Programmable Options *

25.1 Shipping Defaults and Recommended Programming for ANSI/SIA CP-01-2000

SIA CP-01 FEATURE PARAGRAPH # AND DESCRIPTION	DMP PROGRAMMING GUIDE LT-0305 SECTION #	REQUIREMENT	RANGE	SHIPPING DEFAULT	RECOMMENDED PROGRAMMING*
4.2.2.1 Exit Time	6.6 Exit Delay	Required (Programmable)	45 sec. - 250 sec.	60 Seconds	60 Seconds
4.2.2.2 Progress Annunciation	9.12 Prewarn Address (XR40 only)	Allowed	Individual keypads may be disabled per zone	All keypads enabled	All keypads enabled
4.2.2.3 Exit Time Restart	6.6 Exit Delay	Required Option	For re-entry during exit time	Enabled	Enabled
4.2.2.5 Auto Stay Arm on Unvacated Premises	23.3 Occupied Premise - See Install Guide (LT-0624)	Required Option (except for remote arming)	Area 1 = Perimeter Area 2 = Interior	Enabled	Enabled for Residential Applications
4.2.4.4 Exit Time and Progress Annunciation/ Disable - for Remote Arm	Not Available on Remote Arming	Allowed Option	Progress Annunciation Always disabled for Remote Arming	Not Available	Remote Arming not allowed for CP-01 installations.
4.2.3.1 Entry Delay(s)	6.5 Entry Delay	Required (Programmable)	30 sec. - 240 Sec. **	30 Seconds	At least 30 Seconds **
4.2.5.1 Abort Window - for Non-Fire Zones	3.4 Transmit Delay	Required Option	Disable by zone or zone type	Enabled NT DY EX Zone	Enabled
4.2.5.1 Abort Window Time - for Non-Fire Zones	3.4 Transmit Delay	Required (Programmable)	20 sec., 30 sec., or 40 sec. **	30 Seconds	At least 20 Seconds **
4.2.5.1.2 Abort Annunciation	3.4 Transmit Delay	Required Option	Annunciate that no alarm was transmitted	Yes	Yes
4.2.5.4.1 Cancel Annunciation	Always Enabled - Not Programmable	Required Option	Annunciate that a Cancel was transmitted (S49)	Always Enabled	Yes
4.2.6.1 & 4.2.6.2 Duress Feature	User Code + 1 = Ambush Code Not Available	Allowed Option	No 1 + derivative of another user code/no duplicates with other user codes	Code +1 Always Disabled	Not Programmable
4.3.1 Cross Zoning	9.14 Cross Zone	Required Option	Yes/No Zone Programming	No	Enabled using two or more programmed zones
4.3.1 Programmable Cross Zoning Time	6.7 Cross Zone Time	Allowed	4 sec. - 250 sec.	4 Seconds	Per walk path in protected premises
4.3.2 Swinger Shutdown	Not Available – Always On	Required	For all non-fire zones, shut down after 1 trip	Always On	Always On
4.3.2 Swinger Shutdown Disable	9.11 Swinger Bypass	Allowed	For non-police response zones	Yes	Enabled (all zones)
4.3.3 Fire Alarm Verification	9.4 Zone Type	Required Option	FV Type Zone	No	Yes as required (unless sensors can self verify)
4.5 Call Waiting Cancel	3.16 Telephone Number	Required Option	Include *70P in Telephone Number	Disabled	Enabled if user has call waiting

* Programming at installation may be subordinate to other UL requirements for the intended application.
 ** For UL Installations, combined Entry Delay and Transmit Delay should not exceed 1 minute.

False Alarm Reduction Programmable Options (continued)

25.2 Call Waiting (ANSI/SIA CP-01-2000)

The Call Waiting default setting is disabled. To cancel the Call Waiting feature, program * (star) 7 0 P (pause), the standard telephone code prefix that cancels call waiting, into the telephone number string. Cancel Call Waiting for telephone lines that have Call Waiting operational on the telephone line. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).



Caution: A call waiting cancel programmed on a non-call waiting telephone line, would prevent communication to the central station.

25.3 Occupied Premise (ANSI/SIA CP-01-2000)

When only two areas are used, and area one is named Perimeter, and area two is named Interior, and no exit type zone transition occurs during the exit delay because the premise continues to be occupied, the Interior area will automatically disarm at the end of the exit delay.

25.4 Entry Delay (ANSI/SIA CP-01-2000)

Only use Entry Delay 1. Do not use Entry Delay 2. See the XRSuper6/XR20/XR40 Programming Guide (LT-0305).

25.5 Local Bell (ANSI/SIA CP-01-2000)

All non-fire zones such as Night, Day, Exit, Aux1 and Aux 2 must be programmed for local bell enabled with a bell cutoff time set to a minimum of 6 minutes to provide a cancel window of 5 minutes or greater. This does not apply to manually operated zone types such as Panic and Emergency.

25.6 Minimum Installation Requirements (ANSI/SIA CP-01-2000)

SIA CP-01-2000 minimum system installation requirements include an XRSuper6, XR20, or XR40, a UL listed local Bell, and off premise DACT communication to an SCS-1R receiver plus one of the following compatible keypads.

- 690/690F, 790/790F Security Command™ keypads
- 693/793 Easy Entry™ keypads
- 7060, 7063, 7070, or 7073 Thinline™ keypads
- 7060A, 7063A, 7070A, or 7073A Aqualite™ keypads
- 7760 Clear Touch™ keypad

Troubleshooting

26.1 Troubleshooting Section

This section of the Installation Guide provides troubleshooting information for use when installing or servicing an XRSuper6/XR20/XR40 system.

Problem	Possible Cause	Possible Solutions
Keypad displays "SERVICE REQUIRED"	J16 Jumper is installed.	Remove the J16 reset jumper.
	Open or short on the green data wire to the keypad.	Check for broken or shorted wires between the panel and the keypad.
	Bad keypad or zone expander.	Replace with a new or repaired keypad or zone expander.
Keypad display is not functional. When a key is pressed, only a short beep is emitted.	Open or short on the yellow data wire to the keypad.	Check for broken or shorted wires between the panel and the keypad.
	Bad keypad or zone expander.	Replace with a new or repaired keypad or zone expander.
Keypad beeps when keys are pressed, but will not allow the user to arm or disarm, or enter the User Menu.	Two or more keypads are assigned to the same address.	Set each keypad on the system to a unique address.


26.2 Common LCD Keypad Displays

Listed below are several keypad messages you may see on the display. Follow the instructions in the Possible Solutions column to correct the problem.


Message	Meaning	Possible Solutions
INVALID CODE	The user code you have entered is not recognized by the system.	Check the user code and try again.
LATE TO CLOSE (XR20/XR40 Only)	The system was not armed at its scheduled closing time.	Users still on the premise should arm the system or extend the schedule to a later time.
AC TROUBLE	The system is not getting proper power.	Check that the AC connections are good.
BATTERY TROUBLE	The battery is either low or missing.	Check that the battery connections are good and the battery is still good.
PHONE LINE TROUBLE	The panel is looking for phone jack supervision.	Install a jumper wire between terminals 2 and 7 on the phone jack.
SYSTEM TROUBLE or SERVICE REQUIRED	There is a problem with one or more components in the system.	Make sure the J16 jumper is removed from the panel. Make sure there is not a short or open condition on the green data wire to the keypad. You may also need to check that all of the keypads and expansion modules on the bus are good.
SYSTEM BUSY	The system is performing another task with a higher priority.	Wait a few moments for the system to complete the task. Make sure the J16 jumper is not on the panel. If the message displays for a long period of time, the processor could be locked up.
4-WIRE BUS TROUBLE	There is not a supervised device on the bus.	Program a device to be supervised.
	There is low voltage or an open yellow wire.	Make sure all wires are connected.
	Two devices share the same address.	Program one of the devices to a unique address.
TRANSMIT FAIL	The panel has attempted to communicate with the central station 10 times and has not succeeded.	Verify your communication type, account number, and phone number. Make sure the telephone line is connected and working properly.
MAN NUMBER	A service man number has been assigned using Remote Link.	Enter your Service Man Code to obtain access to the panel.

Wiring Diagrams

27.1 Multiple Indicating Circuit Module Installation



27.2 Installation for Derived Channel Burglary



INTERFACING STU-2Z/STU-4Z TO THE XRSuper6/XR20/XR40 PANELS

The STU-2Z or STU-4Z may only be used in conjunction with telephone systems that support DCX Systems Derived Channel multiplex network. The STU-2Z or STU-4Z can only be installed in a DMP Model 350 enclosure.

Burglary

The STU-2Z and STU-4Z are cross listed with the XRSuper6/XR20/XR40 panels as an accessory for Grade AA Central Station Burglar Alarm. For Grade AA, the following conditions must be met:

- The panel must be installed and programmed to meet Grade A burglary alarm system requirements.
- The panel must be installed and programmed for reporting all alarm conditions through the integral DACT to the same central station that monitors the STU-2Z or STU-4Z.
- The STU-2Z or STU-4Z must be mounted in the panel enclosure and wired according to Section 32.4 above.
- Once installed, the central station must enable 2-minute off-hook polling of the STU-2Z or STU-4Z.

Supplementary Reporting (for Commercial Burglar Alarm Applications)

The two zones of the STU-2Z or the four zones of the STU-4Z may be used for supplementary reporting by meeting the following requirements.

1. Program Relay Output #1 for all alarm conditions that are required to report alarm on Zone 1 of the STU-2Z or STU-4Z.
2. Program Relay Output #2 for all alarm conditions that are required to report alarm on Zone 2 of the STU-2Z or STU-4Z.

3. Wire the normally-open terminals of Relay Output #1 to Terminal 1 of the STU-2Z or STU-4Z.
4. Wire the common terminal of Relay Output #1 to Terminal 2 of the STU-2Z or STU-4Z.
5. Wire the normally-open terminal of Relay Output #2 to Terminal 3 of the STU-2Z or STU-4Z.
6. Wire the common terminal of Relay Output #2 to Terminal 2 of the STU-2Z or STU-4Z.

Commercial Fire

When the XRSuper6/XR20/XR40 panel is used as a Central Station Alarm Commercial Fire System with one telephone line, in conjunction with DCX Systems STU-2Z or STU-4Z, the following conditions must be met:

- The panel must be installed and programmed to meet commercial fire (reporting) systems requirements.
- The panel must be installed and programmed for reporting all alarm conditions and trouble conditions to the same central station that monitors the STU-2Z or STU-4Z.
- The STU-2Z or STU-4Z must be mounted in the panel enclosure and wired according to Section 32.4 above.
- Once installed, the central station must enable 2-minute off-hook polling of the STU-2Z or STU-4Z.

Installing the STU-2Z/STU-4Z into the DMP Model 350 Enclosure

The STU board is mounted in the left side of the DMP Model 350 enclosure by slipping the optional corner mounting bracket over the edge of the enclosure. Use DCX Part # 27074-002 (2Z) or Part # 27078-001 (4Z). Connect the STU power wires and telco cables to the panel terminals and RJ31X as shown in Section 24.2 above.

OPERATING INSTRUCTIONS MODEL XRSuper6/XR20/XR40 PANELS

When using Model 692 LED Keypad, please refer to 692 User Guide (LT-0275)

NORMAL STANDBY CONDITION

When the system is in the normal standby condition, the keypad shows either the time of day/System Ready or a blank display.

ALARM CONDITION

When the system is in an alarm condition, the keypad keys glow red and the display shows the violated zone name(s) followed by an alarm display.

ARMING THE SYSTEM

Press the COMMAND key until arming options appear. Press Select key under the arming option desired, then enter your user code.

DISARMING THE SYSTEM

All/Perimeter and Home/Sleep/Away Systems: Enter your user code. If the system is in alarm the keypad will display DISARM SILENCE. Press the Select key under DISARM.

Area Systems: Enter your user code. If the system is in alarm the keypad will display DISARM SILENCE. Press the Select key under DISARM.

Important: Disarming during an alarm sends an Abort report to the central station if your system is programmed to send Abort reports! Be sure you want the alarm message cancelled before disarming during an alarm.

ALARM SILENCE

To silence the alarm while the bell or siren is sounding, enter your code number, press the COMMAND key, and press the Select key under SILENCE. This silences the alarm but does not cancel any alarm reports to the central station. Silencing an alarm while the bell is sounding sends an Abort report to the central station if your system is programmed to send Abort reports.

RESETTING DETECTORS

To reset a smoke or other detector, enter the User Menu by pressing the COMMAND key until MENU? NO YES appears in the display. Press the top row key under YES. The display shows ENTER CODE: -. Enter your code number and press COMMAND. The keypad display now shows SENSOR RESET? Press any top row key.

TROUBLE CONDITION

When a device is in a trouble condition, the keypad tones and displays the zone or device name followed by TRBL. Press any top row key to silence.

SYSTEM TESTING

You should test the security system periodically to ensure proper operation. You can do this through a function in the User Menu. After entering the User Menu, press the COMMAND key until SYSTEM TEST? displays. Press any top row key to test the system bell, battery, and communication to the central station receiver.

ALARM SERVICE

If service is required for this system, please contact:

Company _____

Address _____

Telephone _____

Mounting Instructions

Attach the above operating instructions to the front of the panel, or frame and locate adjacent to the panel or a keypad with an alphanumeric display.

Listings and Approvals

ANSI/SIA CP-01-2000 False Alarm Reduction
California State Fire Marshal (CSFM)
FCC Part 15/FCC Part 68 Registration ID CCKUSA-18660-AL-R
Underwriters Laboratories (UL) Listed
ANSI/UL 294 Access Control System Units
ANSI/UL 365 Police Connected Burglar
ANSI/UL 609 Local Burglar
ANSI/UL 636 Holdup Alarm Units and Systems Accessory
ANSI/UL 1023 Household Burglar
ANSI/UL 1076 Proprietary Burglar
ANSI/UL 1610 Central Station Burglar
ANSI/UL 985 Household Fire Warning
Standard Line Security



800-641-4282

www.dmp.com

Made in the USA

INTRUSION • FIRE • ACCESS • NETWORKS

2500 North Partnership Boulevard

Springfield, Missouri 65803-8877

LT-0624 1.02 © 2008 Digital Monitoring Products, Inc. 8063

