Com Series

HOW-TO GUIDE: ECP PASSTHRU





TABLE OF CONTENTS

ECP Passthru Overview	1
Procedure	1
Required Materials	1
Step 1: Mount the Communicator	2
Step 2: Wire the Communicator	2
Step 3: Program the Vista Keypad	4
Step 4: Configure ECP Settings	4
Remotely (Dealer Admin)	4
Locally (Keypad)	5
Troubleshooting	6
Step 5: Remote Programming	7
Set up Remote Link	7
Add the VISTA Panel in Compass	8
Set Up Communication in Compass	9
Configure TCP/IP Settings in Compass	10
Reference	11
Virtual Keypad	11
VISTA Panel Compatibility	12

ECP PASSTHRU OVERVIEW

CellCom and DualCom Universal Communicators enable you to take over and manage ECP panels with connection to the ECP Bus. This feature is called ECP Passthru.

This guide is designed to walk you through ECP passthru installation and setup. For more complete information, refer to the <u>CellCom Installation Guide (LT-1817)</u> or the <u>DualCom Installation Guide (LT-1859)</u>.

Procedure

The installation must follow this procedure:

<u>Step 1</u>: Mount the communicator.

<u>Step 2</u>: Wire the communicator.

Step 3: Program Vista keypad device address 20

Step 4: Configure ECP settings (remotely or locally)

Required Materials

The following software and hardware components are required to perform system takeovers:

- Compatible Honeywell VISTA panel (refer to <u>"VISTA Panel Compatibility"</u>)
- CellCom or DualCom with minimum firmware Version 202
- (Optional) Programming keypad with Model 330 or Model 330-24V programming cable
- (Optional) Cat 5 Ethernet cable
- 18-22 AWG unshielded wire (RYGB)
- Remote Link minimum Version 2.02





STEP 1: MOUNT THE COMMUNICATOR

It is not necessary to remove the PCB from the housing when installing the communicator.

The communicator should be mounted to a wall using the included #6 screws in the mounting holes. Refer to Figure 1 for mounting hole locations.

Mount the communicator in a secure, dry place to protect it from tampering and weather damage. If using a 685 Series Conduit Backbox, refer to the <u>685 Installation Sheet (LT-1431)</u> for mounting instructions.

STEP 2: WIRE THE COMMUNICATOR

The communicator can be connected to the ECP Bus of a VISTA panel. See <u>Table 1</u> and <u>Figure 2</u> for the necessary wiring connections.



Caution: Remove all AC and battery power from the panels before wiring.

- 1. Attach the antenna to the SMA connector. Refer to Figure 1.
- 2. Connect system batteries as needed, then connect the panels to an appropriate power source.
- 3. Connect a programming keypad to the communicator.
 - a. For 12 VDC applications, connect the keypad to the communicator PROG header with a Model 330 programming harness.
 - b. For 24 VDC applications, connect the keypad to the communicator PROG header with a Model 330-24V programming harness with an in-line resistor.
- 4. After programming is complete, remove the keypad and replace the housing cover on the mounted base.
 - **Note:** Address 1 is reserved by the system for programming keypads.

Communicator to ECP Wiring						
Com Series	ECP Bus	Typical Color				
+DC	Keypad Power	Red				
-DC	Keypad GND	Black				
Z4+	Data Out	Yellow				
Z4-	Data In	Green				

Table 1: Wire Connections



Figure 2: ECP Wiring

STEP 3: PROGRAM THE VISTA KEYPAD

Program Vista Keypad Device Address 20

In this step, you will program VISTA Keypad 5 Device Address 20. This enables the VISTA panel to communicate with a CellCom or DualCom. This step must be performed locally at the VISTA panel.

- 1. Power down and then power up the VISTA panel.
- 2. Within 1 minute of powering up the VISTA panel, simultaneously press and hold the **#** and * buttons on the keypad.
- 3. The keypad displays **INSTALLER CODE**. Enter the installer code (default is **4112**), followed by **8 0 0**.
- 4. Enter ***193**, then enter **10**.
- 5. To save and exit programming, enter ***99**.

User Codes in the Ademco/Honeywell Panel

Because the communicator duplicates the panel's user codes, existing user codes in the Ademco/ Honeywell panel, including master, must be added to the communicator. The DualCom must also have user 2 as a master using the same user code as the host panel user 2. This is required to allow codes added via App/Browser to be sent to the host panel. Any new user codes added to the communicator from the Virtual Keypad App will be automatically entered in the Ademco/Honeywell panel.

User codes from the Ademco/Honeywell panel that are designated as master or partition master should be configured as master codes in the communicator.

If the Ademco/Honeywell panel is armed/disarmed from a keypad, the communicator reports an opening/ closing message by user 0 to the central station.

When the communicator is armed by the Virtual Keypad App or VirtualKeypad.com, the Ademco/Honeywell panel is also armed and the communicator reports an opening message. If opening and closing reports are enabled in the Ademco/Honeywell panel, a duplicate message will also be sent to the central station.

Note: Communicators with Version 194 and higher do not require you to log in to the VISTA panel with a master code to manage user codes remotely.

STEP 4: CONFIGURE ECP SETTINGS

For the communicator to properly process data from the VISTA panel, keypad input must be set to **ECP**. You can perform this programming remotely with Dealer Admin or locally with a programming keypad.

Remote programming requires communicators with firmware Version 212 or higher. Local configuration requires communicators with firmware Version 202 or higher.

During configuration, refer to <u>"Troubleshooting"</u> for programming messages and troubleshooting steps.

Remotely (Dealer Admin)

Before programming, ensure the ECP panel's IP address is set as default.

- 1. Go to **Customers**.
- 2. Find and select the system name.
- 3. Go to Full Programming > System Options.
- 4. In Keypad Input, select ECP.
- 5.[•] In **ECP Partition**, enter the number of the partition where you want the communicator to operate.
- 6.[•] Press **Begin ECP Setup**.
- 7.[•] If the host panel is a VISTA 128, turn on **VISTA 128**.
- 8.[•] Enter the host panel's installer code in **VISTA Installer Code**.

9. Press Begin.

10. After setup is complete, Dealer Admin automatically retrieves zones from the host panel. If you need to retrieve zones again later, open **System Options** and select **Get Zones**.

System Options Cross Zone	ECP Setup
Power Fail D	
Swinger Bypass	rips 8 VISTA Installer Code
Reset Swinger By	ass C (0000-9999)
Time Ch	nge 🥑 Beain
Hours from	MT U
4 Keypad I	put ECP -
	6 Begin ECP Setup] Get Zones 10
5 ECP Part	Non 1
Weather Zip	ode 00000

Locally (Keypad)

To advance through the programming menu, press **CMD**. To go back, press the Back Arrow key. To enter a menu, press any select key or area. To select an option, press the select key or area under that option.

Before programming, ensure the ECP panel's IP address is set as default.

- 1. Power up or reset the communicator.
- 2. At the communicator keypad, enter **6653** (PROG) and press **CMD**.
- 3. Advance to **SYSTEM OPTIONS**, then press any select key or area to enter the menu.
- 4. Advance to **KYPD INPUT**, then press any select key or area.
- 5. Select **ECP** by pressing the third select key or area under that option.
- 6. At **ECP PARTN NBR**, enter the number of the partition where you want the communicator to operate. Range is 1 - 8. Default is **1**.
- 7. To save programming, advance to **STOP** and press any select key or area.
- 8. At the communicator keypad, enter 2313 (DIAG) and press CMD.
- 9. Advance to **ECP SETUP** and press any select key or area.
- 10. At ECP SETUP VISTA 128?: If the panel is a VISTA 128, select YES. Otherwise, select NO.
- 11. At INST CODE, enter the ECP panel installer code and press CMD.
- 12. After configuration is finished, the keypad advances to **GET ZONES**. Press any select key or area.

As the communicator retrieves zones from the ECP panel, the number of zones is displayed and incremented as **ZONE CT** (zone count).

Manually Configure Communication with the Ademco/Honeywell Panel

The following steps describe how to configure Ademco/Honeywell control panels to communicate with the communicator. Only use these steps if programming isn't configured automatically with **ECP SETUP**.

- 1. Program Position * 54: Enter O. This enables no signaling delay.
- 2. Program Position * 55: Enter 1. This enables communication to the communicator.
- 3. Program Position * 84: Enter 0. This disables CP01 and allows remote Arm Away.
- 4. Program Position * 193: Enter 1 0. This enables the DualCom ECP Bus address.

If the Ademco/Honeywell panel fails to communicate with the communicator, program Position * 29 to enable the long range radio on the Ademco/Honeywell panel.

Troubleshooting

Message	Meaning	Next Steps
PROGRAMMING	The communicator is attempting to configure ECP panel programming settings for ECP Passthru.	Wait for the configuration attempt to complete. Afterward, a programming status message is displayed (success, fail, or busy).
PROGRAM SUCCESS	The ECP panel has been successfully configured.	Finish configuration at GET ZONES .
PROGRAM FAIL	The ECP panel could not be programmed.	Check wiring connections and communication settings, then retry programming.
BUS IS BUSY	The ECP panel could not be programmed due to high ECP bus traffic.	Wait and retry programming or reduce traffic on the ECP bus, then retry programming.

 Table 2: Programming Messages and Troubleshooting

STEP 5: REMOTE PROGRAMMING

Starting with Remote Link[™] Version 1.93, you can connect a customer's Honeywell VISTA® panel with CellCom, DualCom, or iComSL Series communicators using Honeywell's Compass® software and Remote Link.

Set up Remote Link

The following instructions assume that you already have a basic communicator account added to your Remote Link accounts. To enable ECP Passthru for that account, complete the following steps.

- 1. Right-click Remote Link and select **Run as administrator**.
- 2. Double-click the communicator account to open it.
- 3. Go to Program > System Options.
- 4. To enable communication, go to Keypad input and select ECP. Press OK.
- 5. Go to File > Panel Information.
- 6.[•] In **Connection Information**, enter the VISTA account number in **Ecp Acct**.
- 7. Press **OK**.
- 8. Go to ECP Passthru > ECP Start/Stop Server.
- 9. Minimize Remote Link.



t Re	emote Link	: [1-12]	355] 12355	8				
File	System	Panel	Program	Ecp Passthru	Langua	ige Windo	w Help	
i	Panel Info	mation	Close Pa	Ecp Start/S	Stop serv	er	connect	Diagnostics
				Ecp Passth	iru Log	Alt+F12		

Add the VISTA Panel in Compass

- 1. Open Compass.
- 2. In the lower right corner of the **Customers** page, select **Add**. The **Customer Detail** window opens.
- 3. In Subscriber Data, enter a Receiver number and Account number.
- 4. In the **Panel Data** section, select the VISTA panel model and revision number.
- 5. In Network Device MAC Addr, enter FFFFF.
- 6. Press **OK**.

Receiver	Account	Last Name	First Name	
1	1234	Cust Nume	Thisting	
Business		Voice Phone	Fax	
Address 1		Address 2		
City	State	Zip Code Zig	9 Ext	
user_field_1		user_field_2		
Panel Vista15P	Revision Vista15P-9	Notes		
Class	Panel Phone Number			
Caller ID CallerID	EEProm Firmware			
Communication Device		5 Mass Download Job	Name	

Set Up Communication in Compass

- 1. In **Customers**, double-click the account that you created in the previous section.
- 2. The Panel Editor opens. Go to **Tools > Communications**.
- 3. Go to File > Communication Settings.
- 4. Select **TCPIP Port Settings**.
- 5.[•] To ensure that Compass uses a TCP/IP connection, select a TCP/IP port.
- 6. Press Add.
- 7. Back in **Communication Settings** window, select **Apply**.
- 8. Press **OK**.

Communication Settings		Configure TCPIP Port	23
Ademco/First Alert		5 Select TCPIP Port for Compass : TCPIP 1	9
Modem Settings Select COM ports	<u>C</u> onfigure COM ports	Internet / Intranet Controller	
Standard Modems :	Custom Modems :	(Control Server)	. 1
Ademco CIA 2400 Hayes Accura 144 V4.0 Hayes Optima 336 External		AlarmNeti Website controlserver. alarmnet.com <u>Uk</u> <u>Cancel</u>	<u> </u>
Hayes Smartmodem 1200	▼		
⊻iew	Add Edit Delete All		
🗖 Touch Tone	Dial Out Prefix		
Speaker On Off After Connect	Modem Volume Low		
4 ICPIP Port Settings	8 <u>0</u> K <u>Cancel</u> Apply		

Configure TCP/IP Settings in Compass

- 1. In the lower left corner of the **Compass Communication** window, press **Connect**.
- 2. A dialog pops up to notify you that communication settings must be configured. Press **OK**.
- 3. Select Enable TCP/IP.
- 4. In the **TCPIP Port** dropdown, select the appropriate TCP/IP port.
- 5.[•] Ensure that the **Network Device MAC Addr** is **FFFFF**.
- 6.[•] In **Connection Mode**, select **ECP**.
- 7.[•] Ensure that **AlarmNet-i** is selected.
- 8. Press **Connect**.

Communications	
TCPIP Port	
TCPIP 1	
Connection Details	
	Use Account CSID
	C First Time Communication
	🔽 Acct # in Panel
Network Device MAC Addr	00D02D FFFFFF Save Undo
Connection Mode 6	
IECP _	
AlarmNet-i O Private LAN	
7	
7	8 Connect Cancel

REFERENCE

Virtual Keypad

Virtual Keypad enables users to manage their systems remotely, including arming, disarming, viewing zone status, bypassing zones, view history, manage users, and more.

To use Virtual Keypad for remote management, the configuration must meet the following conditions:

• ECP Panels must be programmed as Stay/Away for remote arming and disarming (No Partitions).

Image: Start and Start an	0 X
WICH SYSTER* ARMING ZONE STATUS W VOED W VOED W VOED W NAWAY Disarmed W WEW ALL Friday, June 5, 2020	(L) •
Image: Start Star	
Image: Star View ALL Friday, June 5, 2020 View ALL	/ ALL
Image: Stary AWAY STAY AWAY Disarmed Image: Stary Image: Stary Away Image: Stary Image: Stary Image: Stary Away Image: Stary Image: Stary	1 î
STAY AWAY Image: Stay AWay Image: Stay Away Image: Stay Away Image: Stay Image: Stay <td></td>	
STAT AWAT Disarmed § THERMOSTATS Q LIGHTS J HISTORY VIEW ALLL day, June 5, 2020	
Disarmed V UGHTS V UGHTS Image: Control of	
HISTORY VIEW ALL ay, June 5, 2020	-
HISTORY VIEW ALL ay, June 5, 2020 じ のいアレゴ お () BACK DOOR り FRONT DOOR	
lay, June 5, 2020	RESH
7 7:59 AM FRONT DOOR Unlocked by	
I JARDAN JANES	
7:46 AM All System Off - Disarmed by JORDAN JONES Lacked Unlocked	
7:45 AM BACK DOOR Locked	
\bigcirc	

VISTA Panel Compatibility

Panel Type	ECP	Remote User Management	Remote Arming/Disarming	Remote Zone Status	Compatible with Compass
VISTA-10SE	Rev 15 or higher	No	No	No	No
VISTA-10P	Yes	Yes	Yes	Yes	Firmware version 2.0 or higher
VISTA-15	Yes	No	No	No	No
VISTA-15P	Yes	Yes	Yes	Yes	Firmware version 5.2 or higher
VISTA-20SE	Rev 12 or higher	No	No	No	No
VISTA-20P	Yes	Yes	Yes	Yes	Firmware version 5.2 or higher
VISTA-20PI	Yes	Yes	Yes	Yes	Firmware version 5.0 or higher
VISTA-21iP	Yes	Yes	Yes	Yes	Yes
VISTA-21iPLTE	Yes	Yes	Yes	Yes	Yes

Note: Vista 32, 40, 50, 128, 250 are not compatible with ECP Virtual Keypad and eSuite.



Designed, engineered, and manufactured in Springfield, MO using U. S. and global components. **LT-2209 21213**

© 2027

INTRUSION • FIRE • ACCESS • NETWORKS

2500 North Partnership Boulevard Springfield, Missouri 65803-8877 800.641.4282 | DMP. com