# New Feature

Dealer Admin has been updated to include the **Remote Key** field for XT75 and XF6 Series Control Panels.

## Remote Key

Dealer Admin now includes the **Remote Key** field in **Remote Options** programming for XT75 and XF6 Series Control Panels.

When a system is added to Dealer Admin, a randomized remote key is added. Dealer Admin automatically connects to the panel using the default key to allow remote functionality. You can also change the current key and enter a new key of up to 16 characters.

To view or change the default key in Dealer Admin, complete the following steps:

1. Go to dealer.securecomewireless.com.
2. Go to **Customers** and select the **System Name**.
3. Go to **Programming**, then select **Remote Options**.
4. Go to **Remote Key** to view or change the default key.
5. If you make any changes, select **Send All Changes** at the top of the screen.

# More Information

To learn more, refer to the following documentation:

- Dealer Admin Help: Retrieve and Send Programming