

734	KP BUS		AX500		AX600	
ADDRESS	DOOR	ZONES	DOOR	ZONES	DOOR	ZONES
RESERVED FOR KEYPAD			501	501-504	601	601-604
2	2	21-24	505	505-508	605	605-608
3	3	31-34	509	509-512	609	609-612
4	4	41-44	513	513-516	613	613-616
5	5	51-54	517	517-520	617	617-620
6	6	61-64	521	521-524	621	621-624
7	7	71-74	525	525-528	625	625-628
8	8	81-84	529	529-532	629	629-632
9	9	91-94	533	533-536	633	633-636
10	10	101-104	537	537-540	637	637-640
11	11	111-114	541	541-544	641	641-644
12	12	121-124	545	545-548	645	645-648
13	13	131-134	549	549-552	649	649-652
14	14	141-144	553	553-556	653	653-656
15	15	151-154	557	557-560	657	657-660
16	16	161-164	561	561-564	661	661-664
734	AX700		AX800		AX900	
ADDRESS	DOOR	ZONES	DOOR	ZONES	DOOR	ZONES
1	701	701-704	801	801-804	901	901-904
2	705	705-708	805	805-808	905	905-908
3	709	709-712	809	809-812	909	909-912
4	713	713-716	813	813-816	913	913-916
5	717	717-720	817	817-820	917	917-920
6	721	721-724	821	821-824	921	921-924
7	725	725-728	825	825-828	925	925-928
8	729	729-732	829	829-832	929	929-932
9	733	733-736	833	833-836	933	933-936
10	737	737-740	837	837-840	937	937-940
11	741	741-744	841	841-844	941	941-944
12	745	745-748	845	845-848	945	945-948
13	749	749-752	849	849-852	949	949-952
14	753	753-756	853	853-856	953	953-956
15	757	757-760	857	857-860	957	957-960
16	761	761-764	861	861-864	961	961-964

AX BUS Supports Only Door Controllers and Wireless Zones.
 AX BUS ZONE not PROG as a DOOR can be PROG as a WIRELESS ZONE.
 NO Keypads or Hardwired Zones on AX BUS.
 NO XR150/350, XR500, 734N/734N-Wifi.

COMPATIBILITY - XR550 ONLY

ADD ON B - 32 DOORS

ADD ON A - 32 DOORS

2 Software Keys Available for Purchase (16 per AX Bus)

16 ADDITIONAL FREE DOORS ON AX BUS

16 DOORS ON KEYPAD BUS (ORIGINAL)

XR550 Firmware Version 111 and Higher - 32 DOORS

PROG Device # in AX BUS Range (CHART INSIDE) Converts LX BUS to AX BUS

AX BUS DOOR EXPANSION - UP TO 96 DOORS

96 DOORS ADDRESSING ON XR550

96 DOORS ADDRESSING ON XR550

KEYPAD BUS ADDRESSING

Keypad Bus Address can have 1 Door Output & 4 Expansion Zones.

The 734 Uses Addresses 2-16 (Address 1 is for Panel Keypad).

EX: 734 KEYPAD BUS ADDRESS OF 2 = DOOR 2 & ZONES 21-24.

EX: 734 KEYPAD BUS ADDRESS OF 14 = DOOR 14 & ZONES 141-144.

AX BUS ADDRESSING

AX-Bus Address can have 1 Door Output & 1 Expansion Zone.

734 Built-in 4-Zone Expander; 3 Extra Zones must be mapped to 734.

EX: 734 ADDRESS OF 1 ON AX500 = DOOR 501 & ZONES 501-504.

EX: 734 ADDRESS OF 2 ON AX500 = DOOR 505 & ZONES 505-508.

EX: 734 ADDRESS OF 1 ON AX700 = DOOR 701 & ZONES 701-704.

(CHART INSIDE USED FOR DOOR DEVICE ADDRESSING ONLY)