

CELLCOMSL SERIES EXTERNAL ANTENNA

Installation Guide

CellComSL Series Universal Communicators are now available with an optional external antenna. Follow these steps to connect the antenna.

- 1** Remove the cover from the universal communicator.
- 2** Place the rubber duck antenna onto the SMA connector. See Figure 1.
- 3** Using your index finger and thumb, twist the antenna until it is securely tightened.




Figure 1: CellComSL Series External Antenna