

1100 SERIES WIRELESS TECH TIPS



LED Survey

Allows 1 person the ability to confirm communication with the wireless receiver or panel while the cover is removed.

STEP 1 Hold a programmed wireless device in the exact desired location.

STEP 2 Press the tamper switch to send data to the panel and determine if communication is confirmed or faulty.

CONFIRM If communication is confirmed, for each press or release of the tamper switch the LED blinks immediately on and immediately off. Repeat this test to confirm five separate consecutive LED blinks.

FAULTY If communication is faulty, the LED remains on for about 8 seconds or flashes multiple times in quick succession. Relocate the wireless device or wireless receiver until the LED confirms clear communication.

TROUBLESHOOTING
WIRELESS

