



# XTLtouch Diagram



**Arming:** Tapping the shield displays an arming options screen.

**Arming:** Press the shield for two seconds, and the system quick arms and starts the exit timer, giving you plenty of time to leave.

**Disarming:** Press the shield for two seconds, and the keypad screen asks you to enter your code to disarm.

**Enter code:** When you open an entry door, the keypad screen asks you to enter your code to disarm.




---



---



---



---

