

## XR150/XR550 Series Control Panels

December 2015

### Version 110 Firmware Update

XR150/XR550 Version 110 (11/20/15) firmware is now available for download on the DMP Dealer Direct Website at <http://dmp.com/dealer>.

Effective January 11, 2016, all XR150/XR550 Series panels will be manufactured with updated Version 110 (11/20/15) firmware. As of February 19, 2016, inventory for the XR150/XR550 Series panels will be completely updated to Version 110 (11/20/15) firmware.

### Features

#### Easy Exit

Version 110 (11/20/15) now supports the Easy Exit Function on Home/Sleep/Away systems. You can use the Easy Exit shortcut key 8, when the system is armed HOME or SLEEP, to restart the exit delay allowing you to exit the premises without disarming the system. For example, you can let a pet out or retrieve the newspaper. After the exit delay time expires, the system automatically rearms.

In addition, while the exit delay countdown is running, you can also press the Easy Exit shortcut key 8 again to cancel the exit delay countdown. For example, the telephone rings before you retrieve the newspaper so you press shortcut key 8 to rearm the system.

#### New History Notifications

New notifications display in the iOS, Android, and MyVirtualKeypad.com apps history, when there are system changes or access control messages generated from the keypad, Remote Link, or Entré. Real-time status needs to be enabled in Programming for Doors, Output, and Zones to display.

Real-time Status Messages:

- Zone # Closed
- Zone # Door Forced Opened
- Zone # Opened
- Output Momentary
- Output Temporal 3
- Output Pulse
- Output On
- Output Off
- Door Locked
- Door Unlocked

Door Access Messages:

- Access granted
- Access Denied
  - Armed Area
  - Failed to Exit
  - Invalid Area
  - Invalid Code
  - Invalid Time
  - Invalid Level

Programming Change Messages:

(Viewed only by the dealer on the [dealeradmin.securecomwireless.com](http://dealeradmin.securecomwireless.com) Dealer Admin Site)

- Programming Menu - Changes are sent after STOP is chosen to exit programming.
- User Menu - Changes are sent when exiting User Menu.
- Remote Link/Entré - Changes are sent upon disconnecting from the panel.

User Inactivity - Sends a message that the User Code has not been used for the number of days programmed in Inactive User Code Audit in System Options of the Programming Menu.

### Obtaining the New firmware

XR150/XR550 Series firmware updates are available for download free of charge on the DMP Dealer Direct Website at <http://dmp.com/dealer>.

