

## Entré Security & Access Management Software

August 2016

### Version 7.9.5 Update

Effective August 5, 2016, all Entré Security & Access Management software is being manufactured as Version 7.9.5 (8/2/16). If your current Entré software is previous to Version 7.9.0, update to Version 7.9.0 before updating to Version 7.9.5 (8/2/16).

### Features

#### Performance Improvements

General performance improvements have been made to hardware tasks and interactions. These enhancements will be particularly noticeable for large, multi-panel installations.

#### Support for Card Plus PIN By Profile

Entré now supports the Card Plus PIN By Profile feature that was made available with XR550 Version 105. Profiles featuring Card Plus PIN can be applied to individual users. Once applied, users are required to present two credentials when requesting access. This offers a higher level of access restriction for select users.

#### 734 Entré Central Station Programming

With Version 7.9.5, 734 Interface Modules can be programmed through Entré Central Station. Previously, installers had to connect to the 734 Interface Module through Remote Link™ software or an onsite hardwired keypad. Installers are now able to program any 734 Interface Module through their Entré Central Station portal.

#### Delete Panels from the Entré Database

To increase database access efficiency, installers and end users can now delete panels through Entré Central Station. If a panel is incorrectly or incompletely added to Entré, it can be deleted to avoid redundant or unnecessary data.

#### Support for XR550 Version 111

Entré supports XR550 firmware up to and including Version 111. New available features include AX-Bus door compatibility.

#### Longer User Codes

Entré now accommodates user codes with up to 12 digits.

#### Support for 96 doors

Support for 96 doors has been added to Entré. Version 7.9.5 is compatible with AX-Bus expansion door controllers on Version 111 of XR550 Series panels. This allows for up to 96 doors per panel.

#### Spanish Translations

Spanish translations are now available for all updated Entré Version 7.9.5 functionality.

## Badge Editor Profile Search Function

Users can now search for a profile when editing or creating a badge. This allows large companies to quickly locate and apply specific profiles without scrolling through a list of all available profiles. See Figure 1.




Figure 1: Badge Editor Profile Search

## New Credential Types

The Credential Types portion of Entré's Personnel Editor now offers more options. Tabs have been added for Keys, Parking Passes, Logins, and Support Documents. See Figure 2. These new sections are for record keeping only and are not sent to the panel.




Figure 2: Additional Credential Types

## Hardware List

In addition to the standard Hardware Tree, Entré now offers an alternative hardware list. This list allows quick sorting, grouping, and management of hardware using search and column headers. See Figure 3.

Name	Status	Type	Usage	Parent	Enabled	Top Alarm State	Top Alarm Description
ATM READER	Disarmed	Area		East Branch	Yes		
COMMON AREA READERS	Disarmed	Area		MAIN BRANCH	Yes		
PERIMETER INTRUSION	Disarmed	Area		MAIN BRANCH	Yes		
INTERIOR INTRUSION	Disarmed	Area		MAIN BRANCH	Yes		
PERIMETER READERS	Disarmed	Area		SOUTH BRANCH	Yes		
COMMON AREA	Disarmed	Area		SOUTH BRANCH	Yes		
ATM READER	Disarmed	Area		SOUTH BRANCH	Yes		
PARKING LOT READERS	Disarmed	Area		MAIN BRANCH	Yes		
COMMON AREA	Disarmed	Area		East Branch	Yes		
INTRUSION POINTS	Disarmed	Area		SOUTH BRANCH	Yes		
INTRUSION POINTS	Disarmed	Area		East Branch	Yes		
PERIMETER READERS	Disarmed	Area		East Branch	Yes		
FRONT ENTRY LOCK	Door Locked	Device	Door	SOUTH BRANCH	Yes		
1ST FLOOR HALL BIO READER	Door Locked	Device	Door	MAIN BRANCH	Yes		
PARKING LOT ENTRY BIO READER	Door Locked	Device	Door	MAIN BRANCH	Yes		
ATM LOCK	Door Locked	Device	Door	SOUTH BRANCH	Yes		
VAULT LOCK	Door Locked	Device	Door	East Branch	Yes		
SIDE DOOR CONTACT	Door Locked	Device	Door	East Branch	Yes		
OPEN SIGN	Off	Output		East Branch	Yes		
LOBBY LIGHTS	Off	Output		East Branch	Yes		
ELEVATOR 1	Off	Output		MAIN BRANCH	Yes		
ELEVATOR 2	Off	Output		MAIN BRANCH	Yes		
PARKING LOT LIGHTS	Off	Output		SOUTH BRANCH	Yes		
SPRINKLERS	Off	Output		SOUTH BRANCH	Yes		
MAIN BRANCH	Online	Panel		DMP Driver	Yes		
East Branch	Online	Panel		DMP Driver	Yes		
SOUTH BRANCH	Online	Panel		DMP Driver	Yes		
SIDE DOOR CONTACT	Normal	Zone	Night	INTRUSION POINTS	Yes		
MAIN DOOR CONTACT	Normal	Zone	Night	INTRUSION POINTS	Yes		
CUSTOMER DOOR CONTACT	Unknown	Zone	Exit	PERIMETER INTRUSION	Yes		
IT ROOM DOOR CONTACT	Normal	Zone	Night	INTERIOR INTRUSION	Yes		
LOBBY MOTION	Normal	Zone	Night	INTRUSION POINTS	Yes		
HALL MOTION	Normal	Zone	Night	INTERIOR INTRUSION	Yes		
TELLER WINDOW MOTION	Normal	Zone	Night	INTRUSION POINTS	Yes		

Figure 3: Hardware List

## Upgrading/Ordering New Software

Entré Security & Access Management Software Version 7.9.5 (8/2/16) is automatically provided to dealers who have previously purchased an Entre license and are current with their Entre support agreement.