

Version 110818-v1.1 Update

Effective December 20th, 2018, all 738T Wireless Translators will be shipped with Version 110818-v1.1 firmware. The following features are available for the 738T Wireless Transmitter with Version 110818-v1.1.

Features

Updated Panel Support

With Version 110818-v1.1 firmware, the available addresses have expanded to include addresses 1-4, making addresses 1-15 available for 738T support. This allows for up to 2 738Ts on an XT30, XT50, and XR150, and up to 4 738Ts on an XR550. XTLtouch and XTLplus will continue to support 1 738T on addresses 5-8.

Improved Takeover Performance

With the updated 738T, the process of pairing with an Interlogix 319.5 MHz wireless door/window sensor with external contacts is now more efficient. Also, it is now easier to take over a contact that was wired into the terminal block of a door/window sensor.

To learn in a transmitter:

1. Place the 738T in **Learn** mode. See the installation guide ([LT-1760](#)) for more details.
2. Ensure the jumper is removed from the A B terminal block on the transmitter.
3. With the external contact in an **Open** state, tamper the transmitter.
4. Observe the Status LED illuminate on the 738T. The transmitter has been learned in and will correctly report zone state changes for the external contact.