

dealeradmin.securecomwireless.com

July 2017

Version 1.5.5 Update

Effective July 10, 2017, the Dealer Admin Site (dealeradmin.securecomwireless.com) is updated to Version 1.5.5 (7/10/17). As of Version 1.5.5 (7/10/17), the following features are now available.

Features

The following features are available for panels with Version 171 firmware or higher.

Technician User Profile

When you add or edit a profile, there is now a check box that allows you to enable the Technician User profile option. This feature is available for XR150/XR550 Series panels.

System Profiles [Cancel] [Save]

Profile Name
Technician

Number 11 **Rearm Delay** 0 **Output Group** 0

Access Areas
☐ PERIMETER
☐ INTERIOR
☐ BEDROOM

Arm / Disarm Areas
☐ PERIMETER
☐ INTERIOR
☐ BEDROOM

Access Schedules
☐ CHURCH
☐ AFTERHOURS

Profile Options

- ☐ Arm
- ☐ Disarm
- ☐ Alarm Silence
- ☐ Sensor Reset
- ☐ Lockdown
- ☐ Door Lock / Unlock
- ☐ Door Access
- ☐ Armed Areas
- ☐ Output On / Off
- ☐ Zone Status
- ☐ Bypass Zones
- ☐ Zone Monitor
- ☐ System Status
- ☐ System Test
- ☐ Profiles
- ☐ User Codes
- ☐ Schedules
- ☐ Extend
- ☐ Time
- ☐ Display Events
- ☐ Service Request
- ☐ Fire Drill
- ☐ Temp Code
- ☐ Anti-Passback
- ☐ Easy Arm / Disarm
- ☐ Use Secondary Language
- ☐ Card Plus PIN
- ☐ WIFI Setup

☒ Technician User

Figure 1: Technician User Profile Option

Sunrise/Sunset Schedules

Sunrise/Sunset schedules use the panel's weather zip code to stay synced with sunrise and sunset times throughout the year. You can now program these schedules through Dealer Admin by navigating to the Favorite, Output, or Time Schedule page. This feature is available for XT30/XT50, XTLplus, and XR150/XR550 Series panels.

Smith Home XTLplus - New Output Schedule

Cancel Save

Output Name
Select Output

Apply to Systems:

Copy to Systems:

Search

Select All Deselect All

Smith Home XTLplus

Times

On

Sun On Time

Mon 15 Min. Before Sunrise

Tue 15 Min. Before Sunrise

Wed 15 Min. Before Sunrise

Thu 15 Min. Before Sunrise

Fri 15 Min. Before Sunrise

Sat On Time

Off

Off Time

30 Min. After Sunset

30 Min. After Sunset

30 Min. After Sunset

30 Min. After Sunset

30 Min. After Sunset

Off Time

On

Sunrise /set Sunrise

Before 15 Min. Before

Off

Sunrise /set Sunset

Before 30 Min. After

Figure 2: Adding a Sunrise/Sunset Schedule

Output Arming Types

Outputs can now be assigned to arming types. When assigning an output to an arming type in panel programming, only the appropriate options for the arming type will display. This feature is available for XT30/XT50 and XTLplus Series panels only.

Output Schedules

Output schedules are now supported for outputs 51-54 and 61-64 on XTLplus Series panels. One schedule is available for each output.

Send User Codes to Z-Wave Locks

Now, there is a check box on the **System User Codes** page that allows you to select which user codes are sent to Z-Wave locks. This box appears when a system has had Z-Wave locks enabled through the Dealer Admin Site. Checking the box sends the selected user code to the lock, un-checking the box removes the user code from the lock. User codes 2 through 20 can be sent. This feature is available on XT30/XT50 and XTLPplus Series panels only.

XT50 Desk

System User Codes

Cancel Save Delete

User Code:

User Name: WILL

User Number: 0002

User Code: ****

☒ Master ☐ Arm Only ☐ Temporary ☒ Send to Locks

Select Areas for this User

☒ 01 PERIMETER

☒ 02 LIVING AREA

☐ 03 ATTIC

Apply to Systems:

Search: []

Select All Deselect All

☐ XT50 Home Desk

☐ XTLP Home

☒ XT50 Desk

Figure 3: Send to Locks Check Box