

#### Version 1.4.0 Update

Effective September 23, 2015, the vk.securecomwireless.com Dealer Admin Site has been updated to Version 1.4.0.

#### Features

##### Multi System Administration

The vk.securecomwireless.com Dealer Admin Site Version 1.4.0 now supports Authority Level for each App user. Click on the Authority Level drop down box to change the user from Standard to Administrator.

##### Authority Level:

Standard (default) - *Enable Reports* is available for each system check marked in the System Access column.

Administrator - In addition to the Enable Reports column, Users and Schedules columns are available for each system check marked in the System Access column.

##### Columns

System Access - When checked, the User is linked to the system(s).

Enable Reports - When checked, both Standard and Administrator Authority level App users can create reports from MyVirtualKeypad.com website.

See the following Technical Update for more information:

- TU-0809 Vk.securecomwireless.com

Users - When checked, the app user with Administrator Authority Level can Add, Edit, or Delete multiple or individual user codes and profiles on multiple or individual systems using the MyVirtualKeypad.com Web site or the Virtual Keypad iOS app. When left unchecked, "No Systems Available" displays on the Users screen of the app Web page.

Schedules - When checked, the app user with Administrator Authority Level can Add, Edit, or Delete multiple or individual schedules on multiple or individual systems using the MyVirtualKeypad.com Web site or the Virtual Keypad iOS app. When left unchecked, "No Systems Available" displays on the Schedules screen of the app Web page.

See the following Virtual App Technical Updates for more information:

- iOS Version 4.8 (TU-0819)
- MyVirtualKeypad.com 1.8 (TU-0821)

#### Edit User for Customer

Email

Authority Level

Administrator

Video Clips

☒ Email Video Clips

	System Access	Enable Reports	Users	Schedules
<input type="checkbox"/> Central Lab				
<input checked="" type="checkbox"/> Central New England Office		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<input type="checkbox"/> Central Office				
<input type="checkbox"/> Central Warehouse				
<input type="checkbox"/> District Office only				
<input checked="" type="checkbox"/> International Office		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<input type="checkbox"/> Midwest-Springfield				
<input type="checkbox"/> North Location				
<input type="checkbox"/> South Location				

## Remote Firmware Updates

The vk.securecomwireless.com Dealer Admin Site Version 1.4.0 now supports remote firmware updates for the following systems:

- XR550/XR350/XR150 Network panels
  - Network or EASYconnect
- XT30/XT50 panels version 123 firmware or higher and using Level M hardware
  - Network, EASYconnect, or Cellular
- iComSL communicators
  - Network or EASYconnect
- CellcomSL communicators version 123 firmware or higher and using Level E hardware
  - Cellular only

## XTLC/XTLN Panel Programming

A new programming option has been added to the Side Navigation Menu to allow programming using essential programming options for the XTLC/XTLN Version 123 (8/27/15) firmware. When the panel programming defaults are acceptable for installation and only basic programming options are needed, Programming allows the installer to quickly enter information without navigating all of the programming menus.

- Receiver IP
- Weather Zip Code
- System (Area, A/P, or H/S/A)
- Hours from GMT
- Wireless Siren Serial#
- Zone Information

**Note:** All standard programming options are still available in the programming menu from the keypad or Remote Link. All programming information that is not displayed is set to the default settings.

See the following Programming Sheets for list of all programming options and defaults.

- XTLC Programming Sheet LT-1095
- XTLN Programming Sheet LT-1238

**Retrieve Programming** - Click to retrieve programming from the system.

**Send Programming to System** - Click to send the programming changes you just completed to the system.

