



712-8 Zone Expansion Module works on both LX Bus and Keypad Bus. A four wire harness is provided and allows modules to be daisy chained together. The two four pin headers are common. Refer to Document LT-0687 for installation instructions.

Note:
Not for use as fire initiating circuit. Zones share a common ground reference.

Architects and
Engineers
CAD Drawings



Digital Monitoring Products
2841 E. Industrial, Springfield, MO 65802

FILE NAME	TITLE	712-8 Expansion Module
DRAWN LK DATE 7-03-03	PART NO.	REV.
CHECKED SCALE NTS		
APPR'VD SHEET 1 OF 1		