# 716T TERMINAL STRIP

# Installation Sheet

## **DESCRIPTION**

The 716T Terminal Strip plugs into the 716 Output Expansion Module to provide terminal block connection in place of the wiring harness.

## COMPATIBILITY

• 716 Output Expansion Module

# 

Figure 1: 716T PCB

### WHAT'S INCLUDED

- One 716T
- Hardware pack

# **INSTALLATION**

Before installation, remove the 716 PCB from its housing.

## Mount the Tray

Refer to Figure 2 in the following steps.

- 1. Insert the screws into the three holes in the tray and screw into the standoffs.
- 2. Align the standoffs in the panel enclosure and gently snap the standoffs into the three-hole formation in the enclosure.
- 3. Attach the last standoff to the upper center of the tray.

#### Install the 716

Carefully slide the 716 into the tray's grooves. See Figure 3.

#### Install the 716T

Refer to Figure 4 in the following steps.

- 1. Carefully snap the 716T into the standoff and the 716's main header.
- 2. Refer to the 716 Output Expansion Module Installation Guide LT-0183 for wiring, addressing, and programming the 716.

# **SPECIFICATIONS**

Dimensions 2.50 W x 1.90 H in. 6.35 W x 4.83 H cm.

# **ORDERING INFORMATION**

716T Terminal Strip




Figure 2: Mount the Tray




Figure 3: Install the 716




Figure 4: Install the 716T

