V-4010B-1 INDOOR/OUTDOOR HD VIDEO CAMERA

Installation Guide



Figure 1: V-4010B-1 Indoor/Outdoor HD Video Camera

DESCRIPTION

The V-4010B-1 is an indoor/outdoor wired or wireless video camera that allows you to view live and recorded clips through the Virtual Keypad[™] app. It also allows for motion-triggered video clip email notifications. To activate the camera, you need an active Dealer Admin account at dealer.securecomwireless.com.

Compatibility

- Any DMP system with an active Virtual Keypad app
- All SecureCom Cameras and NVRs

What is Included?

- One V-4010B-1 Camera
- Camera Mounting Base
- 12 VDC Power Supply
- Mounting Screws and Hex Key

SecureCom

video

MOUNT THE CAMERA

Mount to a Ceiling or Wall

The V-4010B-1 Camera is suitable for both wall and ceiling mounting applications. Ceiling mounting will be covered as an example in this section. However, the same steps may be referenced for wall mounting.

Refer to Figures 2, 3, and 4 during mounting and lens adjustment.

- 1. Using the included template, mark and drill the screw holes for the mounting base.
- 2. Route and connect the power and network cables as necessary.
- 3. Secure the camera with the screws.

Mount with the V-4000 Mounting Plate

If you are mounting the camera to a standard single-gang box, the camera base may not fully cover the box. In these situations, you have the option of using the V-4000 White Steel Mounting Plate which is designed to mount to the single-gang box, providing full coverage.

- 1. Route the camera's power and network cables through the mounting plate and connect as necessary.
- 2. Place the mounting plate in the desired location.
- 3. Using the supplied screws, secure the mounting plate to the single-gang box.
- 4. Using the supplied screws, secure the camera to the mounting plate. Refer to Figure 3.

Adjust the Camera Angle

- 1. Loosen the adjustment nut.
- 2. Adjust the pan direction (0° to 360°).
- 3. Adjust the tilt direction (0° to 90°).
- 4. Rotate the camera (0° to 360°) to adjust surveillance angle.
- 5. Tighten the adjustment nut to complete the installation.



Figure 2: Indoor/Outdoor HD Video Camera





CONFIGURE THE CAMERA

The V-4010B-1 can be configured to communicate to the SecureCom Video server in several ways. The option you choose depends on whether or not a DMP wireless access point (WAP) is available. The following sections outline the step-by-step processes for setting up a V-4010B-1 camera.

Connect to V-IP1006RR WAP

Auto Pair

- 1. Verify that the V-IP1006RR WAP is powered.
- 2. Plug the 12 VDC power supply into the camera power connection, then connect it to a power outlet or connect the PoE Ethernet cable. Auto pairing will begin immediately.

Wireless Connection

- 1. Plug the 12 VDC power supply into the camera power connection, then connect it to a power outlet.
- 2. Use the supplied hex key to remove the cover from the mounting base.
- Press the WPS button on the back of the WAP for up to 1.5 seconds. The Security LED will flash to indicate that the WAP is sending a security key to the camera.
- 4. Within 1 minute of pressing the WPS button on the WAP, press and hold the WPS/RESET button located on the side of the camera for three seconds. Refer to Figure 5. Once the camera and router are fully connected, the WPS LED on the WAP turns on steady.
- 5. Reinstall the cover on the mounting base.

Connect to a Non-DMP WAP with WPS

- 1. Plug the 12 VDC power supply into the camera power connection, then connect it to a power outlet or connect the Ethernet cable for PoE.
- 2. Use the supplied hex key to remove the cover from the mounting base.
- 3. Refer to the router's instruction manual to place the router in WPS mode.
- 4. Within 1 minute of pressing the WPS button on the WAP, press and hold the WPS button on the camera for three seconds. See Figure 4. Once the camera and router are fully connected, the WPS LED on the WAP turns on steady.
- 5. Reinstall the cover on the mounting base.

Use a Wired Connection

- 1. Plug an Ethernet cable with an active Internet connection into the network interface cord on the camera before powering the camera. See Figure 1.
- 2. Plug the 12 VDC power supply into the camera power connection, then connect it to a power outlet or connect the PoE Ethernet cable.

Note: SecureCom recommends marking the Ethernet cable from the customer's router to the WAP to help with network troubleshooting.

WPS/RESET Button

Figure 5: Camera WPS/ RESET Button

ACTIVATE THE CAMERA

Once communication has been established, activate the camera on Dealer Admin. To learn how to add an NVR in Dealer Admin, refer to the V-4408D Installation Guide (LT-1779) or Dealer Admin Help.

Note: Cameras that are not connected to an NVR must be assigned a static IP address or have a DHCP reservation configured.

- 1. Log in to Dealer Admin (dealer.securecomwireless.com).
- 2. To open the **System Information** page, locate the customer and select their system account number.
- 3. To enable video, select Edit. Enable SecureCom Cameras & NVR, then press Save.
- 4. Press the Add Camera button and enter the 12-digit MAC Address located on the back of the camera. Press **Next**.
- 5. Enter a name for the camera.
- 6. Select the camera's time zone. If necessary, select Observe Daylight Savings Time.
- 7. If the camera image needs to be inverted due to mounting position, at Flip Image?, select Yes.
- 8. To allow this camera to record motion-triggered video clips, select **Clips**.
 - a. If you only want this camera to offer a live camera view through the Virtual Keypad app, choose **Never Record Motion**.
 - b. If you want this camera to record video clips any time it detects motion, choose **Always Record on Motion**.
 - c. If you want the camera to record motion-triggered clips only when the system is armed, choose **Record Motion When Armed**.
- 9. To record video clips continuously during the first minute after the system triggers an alarm, select **Record on Alarm**.
- 10. Press Save.

The device status is displayed next to the camera name. Refresh the page to display the latest status. When the camera is active and communicating with SecureCom video servers, the status is displayed as **Active** and a check mark is displayed in the **Network Ready** column.

To view the camera feed during installation, select the camera name under **Video Devices** on the **System Information** page to display a live video feed for the first 60 minutes after activation. This allows the user to position the camera in the desired location. Once 60 minutes has passed, the camera feed can only be seen through the user's Virtual Keypad app.

ADDITIONAL INFORMATION

Enable Email Clips

If the user would like to be emailed video clips, enable Email Clips in Dealer Admin.

- 1. After finding the customer, select their name.
- 2. The Customer Summary page opens. In App Users, find the user's row and select the More icon, then select Edit.
- 3. Select Email Video Clips.
- 4. To keep your changes, press Save.

Email Clips sends emails with a video clip attachment to the app user any time the video camera records a clip to the SecureCom video server.

V-4010B-1 INDOOR/ OUTDOOR HD VIDEO CAMERA

Weight

Camera with stand

Network Wireless

Hardware

Power Consumption

Dimensions ($H \times W \times D$) Camera with stand

Compatibility

Any DMP system with an active Virtual Keypad™ App All SecureCom Cameras and NVRs

INTRUSION . FIRE . ACCESS . NETWORKS

2500 North Partnership Boulevard Springfield, Missouri 65803-8877 800-641-4282 | DMP.com

Specifications

Sensor and Lens

Image Sensor PIR Sensor Video Compression Resolution Frame Rate On-board Storage

1/3" CMOS Sensor Direction Range 97.5 feet H.264, Mpeg4/M-JPEG 720p (1280 x 960) Up to 30 frames per second 64 GB Micro SD/SDXC card

SecureCom

<u>LT-1414 19415</u>

3.75 lbs

IEEE 802.11b/g/n; WEP64/128 bit, WPA/WPA2 Personal, WPS

12 VDC / Max 8 W or PoE

3.86" x 3.49" x 12.94"

(802.3af)