

SCS-150

Programming Sheet

 **Note:** Default values are shown in bold type.

Company _____ Date _____

Address _____ City _____ State _____ Zip _____

Service Code (XR500 Series panels)

Service Code _____ (00000 to 65535)

Receiver Options

Company Name _____ (Up to 16 characters)

Company Name 2 _____ (Up to 16 characters)

Receiver System Number _____ (0 to 9; Default = **1**)

Receiver Key _____ (1 to 8 Alphanumeric characters)

Hours From GMT _____ (0-23; Default **6**)

Dialer Line Monitor **NO** YES

Event Display Priority **STD** ULC

Local IP Address _____ (Default: **192.168.000.250**)

Local Port _____ (1 to 65535; Default **2001**)

Gateway IP Address _____ (Default: **000.000.000.000**)

Subnet Mask _____ (Default: **255.255.255.000**)

Web User Name _____ (1 to 10 characters, Default: **NEW**)

Web Password _____ (1 to 10 characters, Default: **NEW**)

Line Cards

See table on pages 2 & 3

Dialer Lines Setup

See table on pages 2 & 3

Network Line Setup

See table on pages 2 & 3

Host Automation

Host Name _____
(Up to 16 characters, Default: **HOST 1 NAME**)

Host Port Type **SERIAL** NETWORK

Host IP Address _____ (Default: **192.168.000.250**)

Host Port _____ (Default **2001**)

Protocol **TCP** UDP

Start Character _____ (None, 01-12, 14-31; Default **NONE**)

CRC Error Check **NO** YES

Sequence Number **NO** YES

Test Interval Minutes _____ (1-60; Default **1**)

Acknowledge Timeout _____ (1-15; Default **3**)

Line Number Length _____ (0-2; Default **0**)

Retries to Failure _____ (1-15; Default **3**)

Serial Ports

Host Output Baud Rate _____ (300, 600, 1200, 2400, 4800, 9600, 19200, 38400; Default **9600**)

Activity Log Baud Rate _____ (300, 600, 1200, 2400, 4800, 9600, 19200, 38400; Default **1200**)

Print Operation **ALWAYS** NEVER FAIL

Programming Option	Card #1				Card #2				Card #3				Card #4			
Line Cards																
Card Model		NONE	100	101	104		NONE	100	101	104		NONE	100	101	104	
Send Time Change to Panels		NO	YES				NO	YES				NO	YES			NO YES
Dialer Lines Setup (SCS-104 Only)																
Enable Dialer Line #1		NO	YES				NO	YES				NO	YES			NO YES
Enable Dialer Line #2		NO	YES				NO	YES				NO	YES			NO YES
Enable Dialer Line #3		NO	YES				NO	YES				NO	YES			NO YES
Enable Dialer Line #4		NO	YES				NO	YES				NO	YES			NO YES
First Communication Type		DD	CID				DD	CID				DD	CID			DD CID
Second Communication Type		DD	CID	NONE			DD	CID	NONE			DD	CID	NONE		DD CID NONE
Send ANI/DNIS Info		NO	YES				NO	YES				NO	YES			NO YES
Send Caller ID Info		NO	YES				NO	YES				NO	YES			NO YES
Echo Cancel Disable		NO	YES				NO	YES				NO	YES			NO YES
Network Line Setup (SCS-104 Only)																
Enable Network Line		NO	YES				NO	YES				NO	YES			NO YES
Local IP Address (Default: 192.168.000.250)																
Local Port (Default: 2001)																
Gateway IP Address (Default: 000.000.000.000)																
Subnet Mask (Default: 255.255.255.000)																
Passphrase (8-16 Alphanumeric characters)																
S16 and S17 Always		NO	YES				NO	YES				NO	YES			NO YES
Ack Substituted Message?		NO	YES				NO	YES				NO	YES			NO YES
Check-in Table IP Address (Default: 000.000.000.000)																
Check-in Table Port (1-65535; Default: 2005)																
Check-in Table ID (1-255; Default: 1)																

Programming Option	Card #5				Card #6				Card #7				Card #8			
Line Cards																
Card Model		NONE	100	101	104		NONE	100	101	104		NONE	100	101	104	
Send Time Change to Panels		NO	YES				NO	YES				NO	YES			NO YES
Dialer Lines Setup (SCS-104 Only)																
Enable Dialer Line #1		NO	YES				NO	YES				NO	YES			NO YES
Enable Dialer Line #2		NO	YES				NO	YES				NO	YES			NO YES
Enable Dialer Line #3		NO	YES				NO	YES				NO	YES			NO YES
Enable Dialer Line #4		NO	YES				NO	YES				NO	YES			NO YES
First Communication Type		DD	CID				DD	CID				DD	CID			DD CID
Second Communication Type		DD	CID	NONE			DD	CID	NONE			DD	CID	NONE		DD CID NONE
Send ANI/DNIS Info		NO	YES				NO	YES				NO	YES			NO YES
Send Caller ID Info		NO	YES				NO	YES				NO	YES			NO YES
Echo Cancel Disable		NO	YES				NO	YES				NO	YES			NO YES
Network Line Setup (SCS-104 Only)																
Enable Network Line		NO	YES				NO	YES				NO	YES			NO YES
Local IP Address (Default: 192.168.000.250)																
Local Port (Default: 2001)																
Gateway IP Address (Default: 000.000.000.000)																
Subnet Mask (Default: 255.255.255.000)																
Passphrase (8-16 Alphanumeric characters)																
S16 and S17 Always		NO	YES				NO	YES				NO	YES			NO YES
Ack Substituted Message?		NO	YES				NO	YES				NO	YES			NO YES
Check-in Table IP Address (Default: 000.000.000.000)																
Check-in Table Port (1-65,535; Default: 2005)																
Check-in Table ID (1-255; Default: 1)																



Designed, engineered, and
manufactured in Springfield, MO
using U.S. and global components.

LT-0914 25094
© 2025

INTRUSION • FIRE • ACCESS • NETWORKS

2500 North Partnership Boulevard
Springfield, Missouri 65803-8877
800.641.4282 | DMP.com