

CELLCOM™ LTE-V SERIES

Programming Sheet

NAME _____ ACCOUNT NUMBER _____ DATE _____

ADDRESS _____ CITY _____ STATE _____ ZIP _____

💡 Factory default values are shown in **bold**.

COMMUNICATION

Account Number _____ (1 to 65,535, default = **12345**)

Transmission Delay ___ (0, 15 to 45 sec., default = **0**)

Communication Type **CELL**

Test Time ___:___ AM PM

Cell Test Days ___ (0 to 60 days, default = **1**)

Check-In Minutes ___ (0, or 3 to 240 min., default = **0**)

Fail Time ___ (0, or 3 to 240 min., default = **0**)

Receiver 1 Programming:

Alarm Reports NO **YES**

Supv/Trouble Reports NO **YES**

O/C & User Reports NO **YES**

Test Reports NO **YES**

First IP Address _____

First IP Port _____ (default = **2001**)

Second IP Address _____

Second IP Port _____ (default = **2001**)

Receiver 2 Programming:

Alarm Reports **NO** YES

Supv/Trouble Reports **NO** YES

O/C & User Reports **NO** YES

Test Reports **NO** YES

First IP Address _____

First IP Port _____ (default = **2001**)

Second IP Address _____

Second IP Port _____ (default = **2001**)

MESSAGING SETUP

Enable Messaging **NO** YES

System Name _____

Destination 1 _____

Destination 1 User # ___

Destination 2 _____

Destination 2 User # ___

Destination 3 _____

Destination 3 User # ___

O/C SMS **NO** YES

Monthly Limit ___ (0-999, default = **0**)

REMOTE OPTIONS

Remote Key _____

Disarm NO **YES**

SYSTEM REPORTS

Opening/Closing Reports NO **YES**

Zone Restoral Reports NO **YES** DISARM

Send Stored Messages **NO** YES

SYSTEM OPTIONS

Entry Delay 1 ___ (30 to 250 sec., default = **30**)

Exit Delay ___ (45 to 250 sec., default = **60**)

Cross Zone Time ___ (0, 4 to 250 sec., default = **0**)

Power Fail Delay _ (0, 1 to 9 hrs., default = **1**)

Swinger Bypass Trips _ (0 to 6, default = **2**)

Reset Swinger Bypass **NO** YES

Time Changes NO **YES**

Hours from GMT ___ (0 to 23 hrs., default = **6**)

Keypad Input **NONE** ECP DSC

ECP Partition Number _ (1 to 8, default = **1**)

CID Format **DMP** CID 4-2 SIA

OUTPUT OPTIONS

Cutoff Outputs 1 2

Cutoff Time ___ (0 to 15 min., default = **0**)

Comm Fail Output ___ (0 to 2, F1-20, default = **0**)

Armed Output ___ (0 to 2, F1-20, default = **0**)

Remote Arming Output ___ (0 to 2, F1-20, default = **0**)

AREA INFORMATION

Area 1

Area Name _____

Auto Arming **NO** YES

Bad Zones **BYP** FORC REF

Auto Disarming **NO** YES

Area 2

Area Name _____

Auto Arming **NO** YES

Bad Zones **BYP** FORC REF

Auto Disarming **NO** YES

Area 3

Area Name _____

Auto Arming **NO** YES

Bad Zones **BYP** FORC REF

Auto Disarming **NO** YES

Area 4

Area Name _____

Auto Arming **NO** YES

Bad Zones **BYP** FORC REF

Auto Disarming **NO** YES

Area 5

Area Name _____

Auto Arming **NO** YES

Bad Zones **BYP** FORC REF

Auto Disarming **NO** YES

Area 6

Area Name _____

Auto Arming **NO** YES

Bad Zones **BYP** FORC REF

Auto Disarming **NO** YES

ZONE INFORMATION

Assign Area and Disarmed condition for NT, DY, EX, A1, and A2 only. Assign Style for AR only. ZONE TYPE DEFAULTS	Type	Area	Disarmed Open			Disarmed Short			Armed Open			Armed Short			Swinger	Cross Zone	Receiver Routing	Style
	-- NT DY EX FI PN EM SV A1 A2 FV AR	1 - 6	Message	Output *	Action	Message	Output *	Action	Message	Output *	Action	Message	Output *	Action				
			A T L -		S P M F	A T L -		S P M F	A T L -		S P M F	A T L -		S P M F	N o r Y	N o r Y	NORM 1 2 BOTH	TGL ARM DIS STEP MNT
NIGHT	NT		-	O	S	-	O	S	A	O	S	A	O	S	Y	N		
DAY	DY		T	O	S	T	O	S	A	O	S	A	O	S	Y	N		
EXIT	EX		-	O	S	-	O	S	A	O	S	A	O	S	Y	N		
FIRE	FI								A	O	S	A	O	S	N	N		
PANIC	PN								A	O	S	A	O	S	N	N		
EMERGENCY	EM								A	O	S	A	O	S	N	N		
SUPERVISORY	SV								A	O	S	A	O	S	N	N		
AUXILIARY 1	A1		T	O	S	A	O	S	A	O	S	A	O	S	N	N	NORM	
AUXILIARY 2	A2		T	O	S	A	O	S	A	O	S	A	O	S	N	N	NORM	
FIRE VERIFY	FV								A	O	S	A	O	S	N	N		
ARMING	AR		T															TGL
ZONE NAME		* OUTPUTS = 1 TO 2 OR F1-F20. = THIS FUNCTION IS NOT AVAILABLE FOR THIS ZONE TYPE.																
1																		
2																		
3																		
4																		



Designed, engineered, and
manufactured in Springfield, MO
using U.S. and global components.
LT-1818 21203
© 2023

INTRUSION • FIRE • ACCESS • NETWORKS
2500 North Partnership Boulevard
Springfield, Missouri 65803-8877
800.641.4282 | DMP.com