

XT30/XT50

Programming Sheet

NAME _____ ACCOUNT NUMBER _____ DATE _____

ADDRESS _____ CITY _____ STATE _____ ZIP _____

💡 While filling out this programming sheet, keep in mind that factory default values are shown in **bold**.

COMMUNICATION

Account Number ___ _ _ _ _ (1 to 65,535 default = **12345**)

Transmission Delay ___ _ (0, 15 to 45 sec., default = **30**)

Communication Type **DD** CID NET CELL WIFI NONE

Backup Dialer **NO** YES

Backup Cell **NO** YES

Test Time ___ _ : ___ _ **AM** PM

Net Test Days ___ _ (0 to 60 days, default = **1**)

Dialer Test Days ___ _ (0 to 60 days, default = **1**)

Cell Test Days ___ _ (0 to 60 days, default = **1**)

Check-In Minutes ___ _ (0, or 15 to 240 min., default = **0**)

Fail Time ___ _ (0, or 15 to **240** min.)

Send Comm Trouble NO **YES**

First GPRS APN _____

Receiver 1 Programming:

Alarm Reports NO **YES**

Supv/Trouble NO **YES**

O/C & User NO **YES**

Test Report NO **YES**

First Phone Number _____

Second Phone Number

First IP Address ___ _ . ___ _ . ___ _ . ___ _

First IP Port ___ _ _ _ (default = **2001**)

Second IP Address ___ _ . ___ _ . ___ _ . ___ _

Second IP Port ___ _ _ _ (default = **2001**)

Receiver 2 Programming:

Receiver 2 Backup? **NO** YES

Alarm Reports **NO** YES

Supv/Trouble **NO** YES

O/C & User **NO** YES

Test Report **NO** YES

First IP Address ___ _ . ___ _ . ___ _ . ___ _

First IP Port ___ _ _ _ (default = **2001**)

Second IP Address ___ _ . ___ _ . ___ _ . ___ _

Second IP Port ___ _ _ _ (default = **2001**)

NETWORK OPTIONS

Wi-Fi Setup WPS LIST MANUAL TEST

SSID _____

Wireless Security WEP **WPA** NONE

Wireless Key _____

DHCP NO **YES**

Local IP Address ___ _ . ___ _ . ___ _ . ___ _

Gateway Address ___ _ . ___ _ . ___ _ . ___ _

Subnet Mask ___ _ . ___ _ . ___ _ . ___ _

DNS Server ___ _ . ___ _ . ___ _ . ___ _

Programming Port ___ _ _ _ (default = **2001**)

DEVICE SETUP

Device 1

Device Name _____

Device 2

Device Name _____

Door **NO** YES

Network **NO** YES

Wireless **NO** YES Serial # _____

Supervision Time 0 60 **240**

Device 3

Device Name _____

Door **NO** YES

Network **NO** YES

Wireless **NO** YES Serial # _____

Supervision Time 0 60 **240**

Device 4

Device Name _____

Door **NO** YES

Network **NO** YES

Wireless **NO** YES Serial # _____

Supervision Time 0 60 **240**

Device 5

Device Name _____

Door **NO** YES

Network **NO** YES

Wireless **NO** YES Serial # _____

Supervision Time 0 60 **240**

Device 6

Device Name _____

Door **NO** YES

Network **NO** YES

Wireless **NO** YES Serial # _____

Supervision Time 0 60 **240**

Device 7

Device Name _____

Door **NO** YES

Network **NO** YES

Wireless **NO** YES Serial # _____

Supervision Time 0 60 **240**

Device 8

Device Name _____

Door **NO** YES

Network **NO** YES

Wireless **NO** YES Serial # _____

Supervision Time 0 60 **240**

REMOTE OPTIONS

Remote Key _____

Manufacturer Authorization **NO** YES

Armed Rings ___ _ (0 to 15, default = **8**)

Disarmed Rings ___ _ (0 to 15, default = **8**)

Alarm Receiver **NO** YES

Service Receiver NO **YES**

Disarm NO **YES**

App Key _____

SYSTEM REPORTS

Opening/Closing Reports **NO** YES

Abort Reports **NO** YES

Zone Restoral Reports NO **YES** DISARM

Bypass Reports NO **YES**

Code Change Reports **NO** YES

Send Stored Messages **NO** YES

Ambush Reports **NO** YES

Late To Open Minutes ___ _ (0 to 240 min.)

Early To Close Minutes ___ _ (0 to 240 min.)

Entry Check-in Protection NO **YES**

SYSTEM OPTIONS

System

Area **A/P** H/S/A

Closing Code **NO** YES

Closing Check **NO** YES

Entry Delay 1 ___ _ (**30** to 250 sec.)

Entry Delay 2 ___ _ (30 to 250 sec., default = **60**)

Exit Delay ___ _ (45 to 250 sec., default = **60**)

Cross Zone Time ___ _ (**0**, 4 to 250 sec.)

Power Fail Delay ___ (0, **1** to 9 hrs.)

Swinger Bypass Trips ___ (0 to 6, default = **2**)

Reset Swinger Bypass **NO** YES

Zone Activity Hours ___ (0 to 9 hrs.)

Arm Activity Days ___ (0 to 99 days)

Time Change NO **YES**

Hours from GMT ___ _ (0 to 23 hrs., default = **6**)

Time Display	NO	YES
House Code	— —	(0 to 50)
Detect Wireless Jamming	NO	YES
Wireless Audibles	ANY	DAY MIN
Built-In 1100 Wireless	NO	YES (XT50 Only)
Wireless Encryption	ALL	BOTH NONE
Enter Passphrase	*****	
Enable Keypad Panic Keys	NO	YES
Occupied Premises	NO	YES
Use False Alarm Question	NO	YES
Weather Zip Code	— — — —	Default = 0
EOL Selection	1K	2.2K
Celsius Temperature Option	NO	YES

BELL OPTIONS

Bell Cutoff Time	— —	(0 to 15 min., default = 5)
Automatic Bell Test	NO	YES
Bell Output	— —	(0 to 4, 31-34, 41-44, F1-F20)
Bell Action . . .		
Fire Zones	Steady	Pulse Temporal None
Burglary Zones	Steady	Pulse Temporal None
Supervisory Zones	Steady	Pulse Temporal None
Panic Zones	Steady	Pulse Temporal None
Emergency Zones	Steady	Pulse Temporal None
Auxiliary 1 Zones	Steady	Pulse Temporal None
Auxiliary 2 Zones	Steady	Pulse Temporal None
Carbon Monoxide (CO)	Steady	Pulse Temporal 4 None

OUTPUT OPTIONS

Cutoff Output	1 2 3 4
Cutoff Time	— — (0 to 15 min.)
Comm Fail Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Fire Alarm Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Fire Trouble Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Panic Alarm Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Ambush Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Entry Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Begin Exit Output	— — (0 to 4, 31-34, 41-44, F1-F20)
End Exit Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Ready Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Armed Home Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Armed Sleep Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Armed Away Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Armed All Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Armed Perim Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Armed Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Disarmed Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Burglary Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Arm-Alarm Output	— — (0 to 4, 31-34, 41-44, F1-F20)
Heat Saver Temperature	— — (0 to 4, 31-34, 41-44, F1-F20)
Cool Saver Temperature	— — (0 to 4, 31-34, 41-44, F1-F20)
Carbon Monoxide (CO)	— — (0 to 4, 31-34, 41-44, F1-F20)
Zone Monitor Output	— — (0 to 4, 31-34, 41-44, F1-F20)

OUTPUT SETUP

Output 1	
Output Name	— — — — —
Output 2	
Output Name	— — — — —
Output 3	
Output Name	— — — — —
Output 4	
Output Name	— — — — —

OUTPUT SETUP (WIRELESS)

Output 31	
Output Name	— — — — —
Serial #	— — — — —
Supervision Time	0 60 240
Trip with Panel Bell	NO YES
Output 32	
Output Name	— — — — —
Serial #	— — — — —
Supervision Time	0 60 240
Trip with Panel Bell	NO YES
Output 33	
Output Name	— — — — —
Serial #	— — — — —

Supervision Time	0 60 240
Trip with Panel Bell	NO YES
Output 34	
Output Name	— — — — —
Serial #	— — — — —
Supervision Time	0 60 240
Trip with Panel Bell	NO YES
Output 41	
Output Name	— — — — —
Serial #	— — — — —
Supervision Time	0 60 240
Trip with Panel Bell	NO YES
Output 42	
Output Name	— — — — —
Serial #	— — — — —
Supervision Time	0 60 240
Trip with Panel Bell	NO YES
Output 43	
Output Name	— — — — —
Serial #	— — — — —
Supervision Time	0 60 240
Trip with Panel Bell	NO YES
Output 44	
Output Name	— — — — —
Serial #	— — — — —
Supervision Time	0 60 240
Trip with Panel Bell	NO YES

Note: Assign Output Numbers 31 to 34 for slow response time wireless outputs (activates within 15 seconds) or 41 to 44 for fast response time wireless outputs (activates within 1 second). Assign an 1135 Wireless Siren to any output number and it operates with a fixed 3 second response.

AREA INFORMATION

Area 1	
Area Name	— — — — —
Auto Arming	NO YES
Bad Zones	BYP FORC REF (When using Schedules)
Auto Disarming	NO YES
Area 2	
Area Name	— — — — —
Auto Arming	NO YES
Bad Zones	BYP FORC REF
Auto Disarming	NO YES
Area 3	
Area Name	— — — — —
Auto Arming	NO YES
Bad Zones	BYP FORC REF
Auto Disarming	NO YES
Area 4	
Area Name	— — — — —
Auto Arming	NO YES
Bad Zones	BYP FORC REF
Auto Disarming	NO YES
Area 5	
Area Name	— — — — —
Auto Arming	NO YES
Bad Zones	BYP FORC REF
Auto Disarming	NO YES
Area 6	
Area Name	— — — — —
Auto Arming	NO YES
Bad Zones	BYP FORC REF
Auto Disarming	NO YES

ZONE INFORMATION

[illegible]

ZONE INFORMATION (CONTINUED)

XT30/XT50 Zone Information		Key Fob	Type	Area	Wireless	Contact	External Contact N/O?	114 Contact	Supervision Time	LED Operation	Disarm-Disable	PIR Pulse Count	Sensitivity	Pet Immunity	Disarmed Open			Disarmed Short			Armed Open			Armed Short			Prewarn	Chime	Entry Delay	Cross Zone	Priority	Traffic Count	Zone Audit Days	Receiver Routing	TGL ARM DIS STEP MNT	Style
Assign Area and Disarmed condition for NT, DY, EX, A1, and A2 only. Assign Prewarn and Entry Delay for EX only. Assign Style for AR only. Assign 31 to 34 or 41 to 44 to Key Fobs. Wireless output modules can be assigned to 31 to 34 and 41 to 44.		N	NT			INT	N	1	0	N	N	2	Low	N	N	-	O	S	-	O	S	A	S	N	1	DB	1	N	N	N	0	NORM	1			
		N	DY			INT	N	1	240	Y	Y	4	Low	N	N	T	O	S	T	O	S	A	O	S	Y	1-8	DB	1-2	N	N	N	0				
		N	EX			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	Y	1-8	DB	1-2	N	N	N	0				
		N	FI			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0				
		N	PN			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0				
		N	EM			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0				
		N	SV			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0				
		N	A1			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0	NORM	0		
		N	A2			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0	NORM	0		
		N	FV			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0	NORM	0		
Zone Type Defaults		N	AR			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0			TGL	
		N	CO			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N				N	N	N	0				
		N	IN			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N		DB		N	N	N	0				
		N	DB			INT	N	1	240	Y	Y	4	Low	N	N	-	O	S	-	O	S	A	O	S	N		DB		N	N	N	0	NORM	0		
		* Outputs = 31 to 34, 41 to 44, or FI-F20. = This function not available for this zone type.																																		