



XTLtouch LAB GUIDE

Instructor-Led Training

IDENTIFY PANEL COMPONENTS

1. Identify the following panel components using your panel or the on-screen photo:

- › Reset button
- › Cellular Connector
- › 1100 Series Wireless LEDs
- › Programming header
- › USB Connector
- › Wi-Fi Radio
- › DC Power Terminals
- › Wi-Fi LED

POWER UP THE CONTROL PANEL

1. DC power: Connect to terminals on the XTLtouch PCB
 - › Transformer type: 12 VDC at 500 mA
2. USB: Connect to USB terminal on back of XTLtouch

ENTER PANEL PROGRAMMER

1. Reset the panel using the **RESET BUTTON**
2. Enter **6653** (PROG) at the keypad
3. Press **CMD** to navigate the panel Programmer menu:
 - › Initialization
 - › Remote Options
 - › Output Setup
 - › Fast Program
 - › System Reports
 - › Area Information
 - › Communication
 - › System Options
 - › Zone Information
 - › Network Options
 - › Bell Options
 - › Stop
 - › Device Setup
 - › Output Options
 - › Set Lockout Code

ADJUST COMMUNICATION TYPE

4. Navigate to **COMMUNICATION** and press a top-row select area
5. Press a top-row select area to clear the default account number
6. Enter in a new account number
7. Press **CMD** until **COMM TYPE** displays
8. Press a top-row select area to display the communication types
9. Select **WI-FI**
10. Press **CMD** to exit **COMMUNICATION**

ADD PANEL TO A WIRELESS NETWORK

1. Navigate to **NETWORK OPTIONS** and press a top-row select area
2. **LIST** will show all nearby wireless network (SSID)
3. **MANUAL** will allow manual SSID entry

CONFIGURE SYSTEM OPTIONS

1. Navigate to **SYSTEM OPTIONS** and press a top-row select area
2. Press **CMD** to navigate to **ENTRY DELAY 1**
3. Press a top-row select area and choose a time from 30 to 250 seconds
4. Repeat this process for **ENTRY DELAY 2**
5. Press **CMD** to navigate to **EXIT DELAY**
6. Press a top-row select area and enter a time from

45 to 250 seconds

7. Press **CMD** to navigate to **HOURS FROM GMT**
8. Press a top-row select, enter in the appropriate hours from GMT for your location and press **CMD**
9. Using **CMD**, navigate to **ENTER WEATHER ZIP CODE**
10. Press a top-row select area and enter a **LOCAL ZIP CODE** to display weather alerts at the keypad

ADD A WIRELESS ZONE

1. Navigate to **ZONE INFORMATION** and press a top-row select area
2. Add a zone called 'Office Door'
3. Enter a **ZONE NUMBER** and press **CMD**
4. Press a top-row select area and enter a **ZONE NAME**
5. Press a top-row select area and select a **ZONE TYPE**
6. Press a top-row select area to display a list of available areas and select the appropriate area
7. Enter an **8-DIGIT SERIAL NUMBER** and press **CMD** to navigate to the **NEXT ZONE?** prompt
8. After configuring all zone settings, navigate to **STOP** to save changes and exit the Programmer

WIRELESS CHECK-IN TEST

1. At the keypad, enter **8144** (WALK) to enter the **WALK TEST** menu
2. Select **WLS** to begin the wireless check-in test

PIR WALK TEST

1. At the keypad, enter **8144** (WALK) to enter the **WALK TEST** menu
2. Select **PIR** to begin the PIR walk test

DIAGNOSTIC MENU

1. At the keypad, enter **2313** (DIAG) to enter the **DIAGNOSTIC MENU**
2. When the keypad displays **CELL STATUS**, press a top-row select area to begin the **CELL STATUS** test
3. Press **CMD** to navigate to **CELL SIGNAL** and press a top-row select area to begin the **CELL SIGNAL** test
4. Press **CMD**, select **STOP** to exit **DIAGNOSTIC MENU**

ADD A USER CODE WITH PIN

1. At the keypad, press **CMD** until the **USER MENU?** prompt displays
2. Select **YES** and enter **99+CMD** to enter the **USER MENU**
3. Using **CMD**, navigate to **USER CODES?** and press a top-row select area
4. Select **ADD**
5. Select the **USER NUMBER** and press **CMD**
6. Enter in a 4-digit user code and press **CMD**

7. Press a top-row select area to add a **USER NAME** and press **CMD**
8. Press a top-row select area to select the **USER LEVEL**
9. Press **CMD** to save this user

ADD A USER CODE WITH CARD

1. At the keypad, press **CMD** until the **USER MENU?** prompt displays
2. Select **YES**, enter **99+CMD** to enter the **USER MENU**
3. Using **CMD**, navigate to **USER CODES?** and press a top-row select area
4. Select **ADD**
5. Select the **USER NUMBER** and press **CMD**
6. Wave the card over the blue status LED
7. Press a top-row select area to add a **USER NAME** and press **CMD**
8. Press a top-row select area to select the **USER LEVEL**
9. Press **CMD** to save this user

ARM & DISARM

1. Arm the system, trip an alarm and disarm

CHANGE THE SYSTEM TYPE TO H/S/A

1. Enter the panel programmer by entering **6653** (PROG) at the keypad
2. Navigate to **SYSTEM OPTIONS** and press a top-row select area
3. Press a top-row select area to display the list of system types
4. Select **H/S/A** as the system type
5. Exit **SYSTEM OPTIONS**, navigate to **STOP** to save changes
6. Arm, disarm and trip an alarm in H/S/A system type

CHANGE THE SYSTEM TYPE TO AREA

1. Enter the panel programmer by entering **6653** (PROG) at the keypad
2. Navigate to **SYSTEM OPTIONS** and press a top-row select area
3. Press a top-row select area to display the list of system types
4. Select **AREA** as the system type

EDIT AREA NAMES

1. Press **CMD** to navigate to **AREA INFORMATION**
2. Press a top-row select area to enter **AREA INFO**
3. Enter an **AREA NUMBER** and press **CMD**
4. Press a top-row select area to clear any text and enter in a new area name

5. Exit **AREA INFORMATION** and navigate to **STOP** to save changes
6. Arm, disarm and trip an alarm in Area system type

ADD A Z-WAVE MODULE

1. At the keypad, press **CMD** until the **USER MENU?** prompt displays
2. Select **YES** and enter **99+CMD** to enter the **USER MENU**
3. Using **CMD**, navigate to **Z-WAVE SETUP?** and press a top-row select area
4. Select **ADD**
5. When the keypad displays '**PRESS BUTTON ON Z-WAVE DEVICE**' press the button on the front of the lamp module
6. When the panel recognizes the device, it will display '**DEVICE FOUND**'
7. When the keypad displays '**DEVICE ADDED**' press **CMD**
8. Press a top-row select area to name this Z-Wave device and press **CMD**

OPTIMIZE Z-WAVE

1. Navigate to the **Z-WAVE SETUP** menu and press **CMD** to advance the list
2. Select **OPT** to optimize the signal
 - › After adding any Z-Wave device, it is recommended to optimize Z-Wave

CREATE A FAVORITE

1. Navigate to the **Z-WAVE SETUP** menu and press **CMD** to advance the list
2. Select **FAV**
3. Enter a favorite number and name
4. Choose which devices to include in the favorite

CREATE A FAVORITE SCHEDULE

1. At the keypad, press **CMD** until the **USER MENU?** prompt displays
2. Select **YES** and enter **99+CMD** to enter the **USER MENU**
3. Using **CMD**, navigate to **SCHEDULES?** and press a top-row select area
4. Select **FAV** to create a favorite schedule
5. Enter a **FAVORITE NUMBER** and press **CMD**
6. Select a day of the week and program the **ACTIVATE** time
7. If this schedule will be following sunrise or sunset times, press the second select area, then choose **SUNRISE** or **SUNSET**.
 - › Sunrise and Sunset times require a ZIP code to be entered in System Options
8. Continue this process for every day of the week
9. Press the **BACK ARROW** to exit the **USER MENU**

